




ACCORD

**electrical
troubleshooting
manual**

1989



In this manual:

 **WARNING** Indicates a strong possibility of severe personal injury or loss of life if instructions are not followed.

CAUTION: Indicates a possibility of personal injury or equipment damage if instructions are not followed.

NOTE: Gives helpful information.

CAUTION: Detailed descriptions of *standard* workshop procedures, safety principles and service operations are not included. Please note that this manual does contain warnings and cautions against some specific service methods which could cause **PERSONAL INJURY**, or could damage a vehicle or make it unsafe. Please understand that these warnings cannot cover all conceivable ways in which service, whether or not recommended by American Honda, might be done, or of the possible hazardous consequences of each conceivable way, nor could American Honda investigate all such ways. Anyone using service procedures or tools, whether or not recommended by American Honda, *must satisfy himself thoroughly* that neither personal safety nor vehicle safety will be jeopardized.

All information contained in this manual is based on the latest product information available at the time of printing. We reserve the right to make changes at any time without notice. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of the publisher. This includes text, figures and tables.

Contents

How To Use This Manual	1
Troubleshooting	10
Harness Routing	16
Fuse Information	22
Harness Connector Views	300
Circuit Schematics	(see Circuit Index)

Circuit Index

Air conditioner (Carb)	200
Air conditioner (EFI)	202
Automatic seat belt	264
Automatic transmission interlock	276
Back up lights	104
Blower	192
Brake lights	96
Brake warning system	128
Charging system	222
Choke heater	222
Cigarette lighter	122
Clock	122
Console lights	108
Coolant temperature gauge	146
Cruise control	226
Dash lights	108
Door courtesy lights	114
Electronic fuel injection (EFI)	248
Emission controls	238
Fans (Carb)	200
Fans (EFI)	202
Front side marker lights	90
Fuel gauge	146
Fuel pump (Carb)	210
Fuel pump (EFI)	249
Ground distribution	44
Hazard lights	84, 90
Headlights	74
Headlight retractors	78
Heater controls	196
Horn	70
Ignition	214
Ignition key light	124
Interior light	118
Key warning	124
License plate lights	100
Lights-on warning	136
Low fuel warning system	140
Oil pressure warning system	132
Parking lights	90
Power antenna	156
Power distribution	24
Power door locks	166
Power mirrors	172
Power windows	158
Radio	152
Radio-Bose®	280
Rear window defogger	184
Rear wiper/washer	180
Safety indicator	118
Seat belt warning	124
Shift position indicator	144
Starting system	218
Sunroof	188
Tachometer	150
Taillights	100
Trailer adapter	170
Trunk/hatch light	118
Turn signal lights	84
Warning indicators	140
Wiper/washer	176

First Edition 12/88
All Rights Reserved

American Honda Motor Co., Inc.
Service Publications

How To Use This Manual

Page Numbering System

This manual divides the electrical system into individual sections. Each section has a unique section number. For example, the wiper/washer circuit is section 90, the wiper/washer-pulse circuit is section 91, and the rear wiper/washer circuit is 92. The Component Location photographs, Harness Connector views, and Harness Routing drawings are at the back of the manual in sections 201, 202, and 203 respectively.

Within a section, the first section page uses the section number and then the remaining pages are numbered using the section number, a dash, and then a consecutive number. So, if there are three pages in section 90, the pages will be numbered 90, 90-1, and 90-2.

In addition, the sections are not numbered sequentially, and in many cases, numbers have been left out to leave room for possible additions to reflect the new features for next year or new model types.

Outline of Each Circuit Section

Each circuit section will have a **Circuit Schematic** (wiring diagram), a **Component Location Index**, and a **System Description**. Certain complex circuits will also have **System Operation** charts, **Quick-Checks**, and **Troubleshooting** procedures.

1. A **Circuit Schematic** starts off each section. Schematics show:
 - how all the components within a circuit work together.
 - current flow from the power source (at top of page) to ground (at bottom of page).
 - switch positions (shown "at rest" as if the ignition was off).
 - special instructions ("Solid-State: Do not check resistance").
 - those circuits sharing a common power source or ground.
2. A **Component Location Index** follows each schematic and lists:
 - major components, connectors, and grounds for that particular schematic.
 - the physical locations of each component, connector, and ground.
 - the number of cavities within and the color of each connector.
 - the page number showing photos of each component, connector, and ground.
3. A **System Description** follows the index, and gives a concise explanation of the basic operation of that particular circuit.
4. A **System Operation** chart follows (if required), which describes how the circuit should normally operate, to help you quickly validate the symptom.
5. Next, a list of **Quick-Checks** follows (if required) explaining how to quickly test for proper operation of fuses, grounds, and components without the help of any special equipment. For example: "Check fuse 13 by sounding the horn."
6. Last are the **Troubleshooting** procedures (if required), which are step-by-step instructions leading to diagnosis and repair.

How To Use This Manual

Symbols

The abbreviations and symbols explained here are used throughout the manual; you'll need to know what they mean before you can use the schematics effectively.


Wire Color Abbreviations

The following abbreviations are used to identify wire colors in the circuit schematics:

BLK.....	black
BLU	blue
BRN.....	brown
GRN.....	green
GRY	gray
LT BLU	light blue
LT GRN.....	light green
ORN.....	orange
PNK	pink
RED.....	red
WHT.....	white
YEL.....	yellow

Wires

A wavy line means the wire is broken by the binding of the book but continues on the next page.




Wire insulation can be one color, or one color with another color stripe. (The second color is the stripe.)




This means the current path continues on another page. (The arrow shows direction of current flow.) To follow the white wire in this example, you would turn to the Power Distribution schematic and look for the "P" arrow.




This means the wire connects to another circuit. The wire is shown again in the circuit the arrow is pointing to.



A broken line means only some of the circuit is shown; refer to the circuit listed for the complete schematic.




Wire choices for options or different models are labeled and shown with a "choice" bracket like this.





Where separate wires join, only the splice is shown; for details on the additional wiring, refer to the circuits listed.

OK here if Horn works; if not, see Power Distribution, page 20.




This dashed line means the BLU/RED and RED/BLU wires are both in connector C134. See Connectors, page 3.






Splices — “S”

Splices (S) are numbered and shown as a dot. The location and connection of these splices may change depending on manufacturer.





Connectors — “C”


Each connector (C) is numbered for reference in the component location photographs.




Next to each connector is the total number of cavities and the color of the connector. If nothing is listed, a one pin connector is shown. Wires may not be used in all cavities.




This means the connector connects directly to the component.



This indicates the connector connects to a lead (pigtail), wired directly to the component.




This indicates a screw terminal on the component.



Components


A solid line means the entire component is shown.



A broken line indicates only part of the component is shown.



The name of the component appears next to its upper right corner.



Notes about component function follow its name.

Grounds — “G”

This symbol means the end of the wire is attached to a metal part of the car.



Each wire ground (G) is numbered for reference in the component location photographs.

This ground symbol (dot and 3 lines) overlapping the component means the housing of the component is attached directly to a metal part of the car.




(cont'd)

How To Use This Manual


Symbols (cont'd)

This represents RFI (Radio Frequency Interference) shielding around a wire. The shielding is always connected to ground.




Switches

These switches move together; a dashed line shows a mechanical connection between them.




This is a relay shown with no current flowing through its coil.



Fuses

This means power is supplied with the ignition in "Run."




Diode


The diode allows current to flow only in the direction of the arrow.



Component Location

Every component, connector, and ground that does not have an obvious location has either a photo reference or a location description following its name. The photo number refers to a photograph shown on the pages following the schematic. The connectors, splices, and grounds are numbered according to their location in the car. "100 series" are located in the front, "200 series" are in the middle (dash area), "300 series" are in the body area (seats and doors) and "400 series" are in the rear.





How to Use This Manual

Circuit Schematics

Circuit schematics break the entire electrical system into individual circuits. Electrical components that work together are shown together. You are not distracted by wiring that is not part of the circuit you are working on.

Each drawing is extended so current flows from positive at the top of the page to ground at the bottom of the page. The "hot" leads at the top of a fuse show where the ignition switch supplies power to that fuse.

Each circuit is shown completely and independently on one schematic. Other circuits getting their power from the same point, or grounding at the same point are not shown. However, if other circuits actually share some wires with the circuit shown, the shared wires of the other circuit will also be shown.

Wires that connect to another circuit are shown with an arrowhead pointing in the direction of current flow. The name of the circuit or component that shares the wiring is provided for reference. You can check shared wiring by checking the operation of the other circuit.

"See Power Distribution" means there are more connections to other circuits that are not shown. All other shared circuits are shown on the Power Distribution circuit schematic. "See Shared Distribution" means there are more shared ground circuits which are shown on the Ground Distribution schematic.

The note "OK, Here's Your Door Courtesy Light" means it not see Power Distribution page. It is a troubleshooting aid. Check the driver's door courtesy light by pressing the driver's door. If the light goes on the circuit from fuse 13 is okay. 2288 is OK.

Photographs follow the text for each circuit and are referred to on the schematic by number. Above each photo is its reference number and a general description of its location. The photos show the specific component, connector, and ground location.



How To Use This Manual

Circuit Schematics

Circuit schematics break the entire electrical system into individual circuits. Electrical components that work together are shown together. You are not distracted by wiring that is not part of the circuit you are working on.

Each drawing is arranged so current flows from positive, at the top of the page, to ground, at the bottom of the page. The “hot” labels at the top of a fuse show when the ignition switch supplies power to that fuse.


Each circuit is shown completely and independently on one schematic. Other circuits getting their power from the same point, or grounding at the same point are not shown. However, if other circuits actually share some wires with the circuit shown, the shared wires of the other circuits will also be shown.


Wires that connect to another circuit are shown with an arrowhead pointing in the direction of current flow. The name of the circuit or component that shares the wiring is provided for reference. You can check shared wiring by checking the operation of the other circuits.

“See Power Distribution” means there are more connections to other circuits that are not shown. All such shared circuits are shown on the Power Distribution circuit schematic. “See Ground Distribution” means there are more shared ground circuits which are shown on the Ground Distribution schematic.

The note “OK here if Driver’s Door Courtesy Light works; if not, see Power Distribution, page 24” is a troubleshooting aid. Check the driver’s door courtesy light by opening the driver’s door. If the light goes on the circuit from fuse 13 to splice S262 is OK.

Photographs follow the text for each circuit and are referred to on the schematic by number. Above each photo is its reference number and a general description of the location. The photos show the specific component, connector, and ground locations.






Power Distribution

The sample Power Distribution schematic shows how voltage is supplied from the positive battery terminal to the various circuits in the car.

Individual circuit schematics begin with a fuse. Power Distribution shows the wiring between the battery and the fuses. By combining Power Distribution with any individual schematic, you get a complete picture of how voltage is applied to the circuit.

You can use Power Distribution to speed your troubleshooting. If Power Distribution shows that an inoperative circuit and a second circuit share a fuse, check the operation of the second circuit. If it works, you know the fuse is good and voltage is available to the inoperative circuit. You can then continue troubleshooting.



* C420 (8-WHT) Coupe Photo 59
C420 (6-WHT) Hatchback Photo 59
C331 (4-WHT) Sedan Photo 14


(cont'd)


How To Use This Manual

Circuit Schematics (cont'd)

Ground Distribution

This sample Ground Distribution schematic shows which components share the same ground points.





Five-Step Troubleshooting

1. Verify The Complaint

Turn on all the components in the problem circuit to check the accuracy of the customer complaint. Note the symptoms. Do not begin disassembly or testing until you have narrowed down the problem area.

2. Analyze The Symptom

Look up the schematic for the problem circuit. Determine how the circuit is supposed to work by tracing the current paths from the power source through the circuit components to ground. Ask: Does the circuit have a power source? Are there any switches or relays? List the components in the circuit: power source, switch, ground, and so on. Determine the expected behavior of the circuit. If the circuit is supposed to work, the symptom is OK, and the cause must be in the component or the wiring. If the circuit is supposed to fail, the cause must be in the component or the wiring.

Based on the symptoms and your understanding of the circuit's operation, identify one or more possible causes of the problem.

3. Isolate The Problem By Testing The Circuit

Make circuit tests to check the diagnosis you made in step 2. Keep in mind that a logical single procedure is the key to efficient troubleshooting. Test for the most likely cause of failure first. Try to make tests at points that are easily accessible.

4. Fix The Problem

Once the specific problem is identified, make the repair. Be sure to use proper tools and safe procedures.

5. Make Sure The Circuit Works

Turn on all components in the repaired circuit. If all the components are working, the problem is fixed. If the problem was a blown fuse, be sure to test it at the circuit on test. Make sure the original problem does not recur.

Test Equipment

Voltmeter and Test Light

CAUTION: A number of circuits include self-storing devices. Voltages in these circuits should be tested only with a 10-megohm or higher impedance digital multimeter. Never use a test light on circuits that contain self-storing devices. Damage to the device may result.

On circuits without self-storing devices, use a test light to check for voltage. A test light is made up of a 12-volt bulb with a pair of leads attached. After grounding one lead, touch the other lead to various points along the circuit where voltage should be present. The bulb will glow if there is voltage at the point being tested.


A voltmeter can be used in place of a test light. While a test light shows whether or not voltage is present, a voltmeter also indicates how much voltage is present.

Self-Powered Test Light and Ohmmeter

CAUTION: Never use a self-powered test light on circuits that contain self-storing devices. Damage to these devices may result.

Diodes and self-storing devices in a circuit can make an ohmmeter give a false reading. To find out if a component is affecting a measurement, take one reading, reverse the leads, and take a second reading. If the readings differ, the component is affecting the measurement.

An ohmmeter can be used in place of a self-powered test light. The ohmmeter shows how much resistance there is between two points along a circuit. Low resistance means good continuity.



Self-Powered Test Light

Troubleshooting

Five-Step Troubleshooting

1. Verify The Complaint

Turn on all the components in the problem circuit to check the accuracy of the customer complaint. Note the symptoms. Do not begin disassembly or testing until you have narrowed down the problem area.

2. Analyze The Schematic

Look up the schematic for the problem circuit. Determine how the circuit is supposed to work by tracing the current paths from the power source through the circuit components to ground. Also trace circuits that share wiring with the problem circuit. The names of circuits that share the same fuse, ground, or switch, and so on, are referred to on each circuit schematic. Try to operate any shared circuits you didn't check in step 1. If the shared circuits work, the shared wiring is OK, and the cause must be in the wiring used only by the problem circuit. If several circuits fail at the same time, the fuse or ground is a likely cause.

Based on the symptoms and your understanding of the circuit's operation, identify one or more possible causes of the problem.

3. Isolate The Problem By Testing The Circuit

Make circuit tests to check the diagnosis you made in step 2. Keep in mind that a logical, simple procedure is the key to efficient troubleshooting. Test for the most likely cause of failure first. Try to make tests at points that are easily accessible.

4. Fix The Problem

Once the specific problem is identified, make the repair. Be sure to use proper tools and safe procedures.

5. Make Sure The Circuit Works

Turn on all components in the repaired circuit in all modes to make sure you've fixed the entire problem. If the problem was a blown fuse, be sure to test all of the circuits on that fuse. Make sure no new problems turn up; make sure the original problem does not recur.

Test Equipment

Voltmeter and Test Light

CAUTION: A number of circuits include solid-state devices. Voltages in these circuits should be tested only with a 10-megohm or higher impedance digital multimeter. Never use a test light on circuits that contain solid-state devices. Damage to the device may result.

On circuits without solid-state devices, use a test light to check for voltage. A test light is made up of a 12-volt bulb with a pair of leads attached. After grounding one lead, touch the other lead to various points along the circuit where voltage should be present. The bulb will go on, if there is voltage at the point being tested.


A voltmeter can be used in place of a test light. While a test light shows whether or not voltage is present, a voltmeter also indicates how much voltage is present.

Self-Powered Test Light and Ohmmeter


CAUTION: Never use a self-powered test light on circuits that contain solid-state devices. Damage to these devices may result.

Diodes and solid-state devices in a circuit can make an ohmmeter give a false reading. To find out if a component is affecting a measurement, take one reading, reverse the leads, and take a second reading. If the readings differ, the component is affecting the measurement.

An ohmmeter can be used in place of a self-powered test light. The ohmmeter shows how much resistance there is between two points along a circuit. Low resistance means good continuity.



Self-Powered Test Light



Troubleshooting Tests

Testing For Voltage

This test measures voltage in a circuit. When testing for voltage at a connector, you do not have to separate the two halves of the connector. Instead, probe the connector from the back. Always check both sides of the connector, because dirt and corrosion between its contact surfaces can cause electrical problems.

1. Connect one lead of a test light to a known good ground, or if you are using a voltmeter, be sure you connect its negative lead to ground.
2. Connect the other lead of the test light or voltmeter to the point you want to check.
3. If the test light glows, there is voltage present. If you are using a voltmeter, note the voltage reading. It should be within one volt of measured battery voltage. A loss of more than one volt indicates a problem.


Circuits that contain solid-state devices should only be tested with a 10-megohm or higher impedance digital multimeter.

Use a self-powered test light to check for continuity. This tool is made up of a light bulb, battery, and two leads. If the leads are touched together, the bulb will go on.

A self-powered test light is only used on an unpowered circuit. First disconnect the battery or remove the fuse that feeds the circuit you are working on. Select two points along the circuit through which there should be continuity. Attach one lead of the self-powered test light to each point. If there is continuity, the test light's circuit will be completed and the bulb will go on.


Jumper Wire

Use a jumper wire to bypass an open circuit. A jumper wire is made up of an in-line fuse holder connected to a set of test leads. It should have a five ampere fuse. Never use a jumper wire across any load. This direct battery short will blow the fuse.



Short Finder

Short finders are available to locate shorts to ground. The short finder creates a pulsing magnetic field in the shorted circuit and shows you the location of the short through body trim or sheet metal. Its use is explained in the following troubleshooting tests.



(cont'd)


Troubleshooting

Troubleshooting Tests (cont'd)

Testing For Continuity

This test checks for continuity within a circuit. When testing for continuity at a connector, you do not have to separate the two halves of the connector. Instead, probe the connector from the back. Always check both sides of the connector, because dirt and corrosion between contact surfaces can cause electrical problems.


1. Disconnect the negative cable from the battery. If you are using an ohmmeter, hold the leads together and adjust the ohmmeter to read zero ohms.
2. Connect one lead of a self-powered test light or ohmmeter to one end of the part of the circuit you want to test.
3. Connect the other lead to the other end.
4. If the self-powered test light glows, there is continuity. If you're using an ohmmeter, low or no resistance means good continuity.




Testing For Voltage Drop

Wires, connectors, and switches are designed to conduct current with a minimum loss of voltage. A voltage drop of more than one volt indicates a problem.


1. Connect the positive lead of a voltmeter to the end of the wire (or to the side of the connector or switch) closest to the battery.
2. Connect the negative lead to the other end of the wire (or the other side of the connector or switch).
3. Turn on the components in the circuit.
4. The voltmeter will show the difference in voltage between the two points. A difference, or drop, of more than one volt indicates a problem. Check the circuit for loose or dirty connections.






Testing For A Short With A Test Light Or Voltmeter

1. Remove the blown fuse and disconnect the load.
2. Connect a test light or voltmeter across the fuse terminals to make sure that voltage is being applied to the fuse terminals. You may have to put the ignition switch in "RUN;" check the schematic to see.
3. Beginning near the fuse box, wiggle the harness. Continue this at convenient points about six inches apart, while watching the test light or voltmeter.
4. When the test light blinks or the voltmeter needle moves, there is a short-to-ground in the wiring near that point.



Testing For A Short With A Self-Powered Test Light Or Ohmmeter

1. Remove the blown fuse and disconnect the battery and load.
2. Connect one lead of a self-powered test light or ohmmeter to the fuse terminal on the load side.
3. Connect the other lead to a known good ground.
4. Beginning near the fuse box, wiggle the harness. Continue this at convenient points about six inches apart, while watching the test light or ohmmeter.
5. When the self-powered test light blinks or the ohmmeter needle moves, there is a short to ground in the wiring near that point.




(cont'd)


Troubleshooting

Troubleshooting Tests (cont'd)

Testing For A Short With A Short Circuit Locator

1. Remove the blown fuse. Leave the battery connected.
2. Connect the short finder across the battery terminal and the load side of the fuse terminal.
3. Close all switches in series, in the circuit you're testing.
4. Turn on the short circuit locator. It sends pulses of current to the short. This creates a pulsing magnetic field around the wiring between the fuse box and the short.
5. Beginning at the fuse box, slowly move the short finder meter along the circuit wiring. The meter will show current pulses through body trim and sheet metal. As long as the meter is between the fuse and the short, the needle will move with each current pulse. Once you move the meter past the point of the short, the needle will stop moving. Check around this area to locate the cause of the short circuit.





Troubleshooting Precautions

Before Troubleshooting


- Check the main fuse and the fuse box.
- Check the battery for damage, state of charge, and clean and tight connections.
- Check alternator belt tension.

CAUTION:

- **Do not quick-charge a battery unless the battery ground cable has been disconnected, or you will damage the alternator diodes.**
- **Do not attempt to crank the engine with the ground cable disconnected or you will severely damage the wiring.**

While You're Working

- Make sure connectors are clean, and have no loose pins or receptacles.
- Make sure multiple pin connectors are packed with silicone grease.




CAUTION:


- **Do not pull on the wires when disconnecting a connector, pull only on the connector housings.**
- **When connecting a connector, push it until it clicks into place.**
- **Refer to page 10 for cautions about troubleshooting circuits that contain solid-state devices.**

Harness Routing


Engine Compartment

Carbureted






Fuel-Injected







(cont'd)

Harness Routing

Dash, Body, and Doors (cont'd)








* Hatchback and Coupe only


Harness Routing

Rear (cont'd)





COUPE




Fuse Information


Under-Hood Fuse Box

Top View

Bottom View




Fuse Position	Amps	Component or Circuit Protected
1	10	PGM-FI main relay; emission control unit
2	20	Power door lock control unit
3	30	Sunroof relays
4	20	Horn; brake lights; automatic seatbelt; ignition key switch
5	10	Headlight retractor switch
6	15	Right retractor relay
7	15	Left retractor relay
8	10	Alternator
9	15	Radiator fan (EFI)
	30	Radiator fan motor; A/C condenser fan motor (Carb)
10	10	Hazard lights; front side marker lights; integrated control unit
11	10	Emission control unit; clock; radio
12	15	Condenser fan motor
13	15	Lights: interior, door courtesy, ignition key, trunk/hatch, cigarette lighter, trailer, dome
14	15	Radiator fan controller timer
15	20	Left rear power window motor
16	20	Right rear power window motor
17	20	Left front power window motor; power window control unit
18	20	Right front power window motor
19	40	Power distribution
20	40	Condenser fan relay
21	70	Power distribution
22	40	Power distribution
23	30	Rear window defogger
24	30	EFE heater
25	40	Power distribution




Dash Fuse Box

FRONT VIEW




REAR VIEW




Fuse	Amps	Component or Circuit Protected
1	15	Fuel pump cut off relay; emission control unit; alternator; emission control box; EFI main relay; fan controller/timer; warning display; speed sensor amplifier; electronic air control valve
2	10	Safety indicator; clock; coolant temperature gauge; fuel gauge; tachometer; back up lights; integrated control unit; shift indicator panel; warning lights (brake, fuel level, oil pressure, seat belt); automatic seatbelt control unit; shift lock solenoid
3	20	Sunroof relays; wiper motors; washer motors; wiper timer relay; power window relay
4	7.5	Cruise control switch; cruise control indicator
5	10	Rear window defogger relay; rear window defogger indicator; fresh/recirculation motor; heater controls; fans and air conditioner
6 and 7	10	Headlight low beams
8 and 9	15	Headlight high beams; high beam indicator
10	7.5	Bulb check
11	15	Headlight retractor control unit
12	15	Fans and air conditioner; power mirrors; EFE control unit
13	10	Radio; power antenna motor
14	15	Lights: front and rear marker, license plate, tail, dash and console lights, safety indicator
15		Not used


Power Distribution

- Circuit Schematic






UNDER-HOOD
FUSE BOX
Photo 2




(cont'd)


Power Distribution

- Circuit Schematic (cont'd)






From UNDER-HOOD
FUSE BOX on page 25.




(cont'd)


Power Distribution

- Circuit Schematic (cont'd)








*C331 [4-WHT] Hatchback Sedan
Photo 14
C420 [6-WHT] Hatchback Photo 59
C420 [8-WHT] Coupe Photo 59



(cont'd)


- Circuit Schematic (cont'd)







(cont'd)


- Circuit Schematic (cont'd)






Power Distribution


1. Bottom View of Under-hood Fuse Box




2. Under-hood Fuse Box




3. Front View of Dash Fuse Box



4. Rear View of Dash Fuse Box




5. Under Right Front Seat




6. Under Right Side of Dash, Behind Blower Assembly







7. Under Center of Dash




8. Under Left Side of Dash, on Right Side of Dash Fuse Box




9. Under Left Front Seat




10. In Right Center Pillar, Between Front and Rear Doors



11. Under Left Side of Dash, Right of Steering Column




12. Under Carpet, Next to Driver's Door




Power Distribution


13. In Left Center Pillar, Between Front and Rear Doors




14. Right Front of Trunk, Near Speaker




15. Right Front Corner of Engine Compartment, Behind Bumper




16. Left Front Corner of Engine Compartment, Behind Bumper




17. Under Left Side of Dash, Left of Steering Column




18. Under Right Front Seat







19. Right Front of Engine Compartment, Near Radiator




22. Lower Left Rear of Engine




20. Right Side of Engine Compartment, Rear of Battery




23. Right Front Corner of Engine Compartment, Front of Battery



21. Left Front Corner of Engine Compartment, Below Battery




24. Under Left Side of Dash, Left of Steering Column




Power Distribution


25. Under Left Front Seat




28. Under Right Side of Dash, at Kick Panel




26. Under Left Side of Dash, Above Dash Fuse Box




29. Under Left Center of Dash, Behind Heater Assembly




27. Under Left Side of Dash, Left of Steering Column




30. Under Carpet, Next to Driver's Door







31. Left Front Corner of Engine Compartment




34. Under Right Side of Dash, at Kick Panel




32. Left Front of Engine Compartment, Left of Radiator




35. In Console, at Base of Gear Selector



33. Left Side of Dash, Behind I/P




36. Right Rear Corner of Engine Compartment, on Strut Tower




Power Distribution


37. Top Right Side of Steering Column




40. Under Dash, Right of Heater Assembly




38. Right Front of Dash, in Engine Compartment




41. Left Rear of Engine Compartment




39. Under Left Side of Dash, Left of Steering Column




42. Under Passenger's Seat







43. Center Front of Roof




46. Left Center of Rear Hatch




44. Under Left Side of Dash, at Kick Panel




47. Top Rear of Engine



45. Left Rear of Engine Compartment




48. On Steering Column Trim Panel




Power Distribution


49. Center of Dash, Near Radio




52. Right Rear Corner of Trunk




50. On Inner Fender Panel, Behind Right Headlight




53. Left Rear Corner of Trunk




51. Under Left Side of Dash, Below Steering Column




54. Rear Half of Right Door (Panel Removed)







55. Right Rear of Hatch, Behind Access Panel




58. Rear Half of Driver's Door (Panel Removed)




56. Rear Half of Right Door (Panel Removed)




59. Top Left Front of Trunk



57. Behind Front Cigarette Lighter




60. Right Rear Corner of Trunk




Power Distribution


61. Rear Half of Driver's Door (Panel Removed)




62. Under Left Side of Dash



63. Under Center Console





2-10


Diagram of Distribution Grids


Circuit Schematic



Ground Distribution: G102

- Circuit Schematic





Carb

FREQUENCY
SOLENOID
VALVE B
Page 240
Photo 1



C109 [2-WHT]
Photo 1

ANTI-
AFTERBURN
CONTROL
SOLENOID
VALVE
Page 240
Photo 2



FEEDBACK
CONTROL
SOLENOID
VALVE
Page 240
Photo 2



C110 [4-WHT]
Photo 2

A/C IDLE
BOOST
SOLENOID
Page 201
Photo 1



C182 [2-WHT]

G102
Photo 3

EFI

A/C
CONDENSER
FAN MOTOR
Page 202
Photo 6




C140 [2-WHT]
Photo 6


G102
Photo 3

Ground Distribution


1. Left Side of Engine Compartment




2. Left Rear Corner of Engine Compartment




3. Left Front of Engine Compartment, Behind Headlight



4. Left Front Corner of Engine Compartment, Behind Bumper




5. On Left Inner Fender Panel, Behind Headlights




6. Left Front of Engine Compartment, Behind Radiator






7. Left Rear Corner of Engine Compartment



8. Left Side of Engine Compartment, Front of Shock Tower



9. Behind Lower Left Corner of Bumper




Fig. 1. The layout of the experimental apparatus.



Fig. 2. The layout of the experimental apparatus, front view.



Fig. 3. The layout of the experimental apparatus, back view.







Front Distribution: G100

Front Schematic




- Circuit Schematic







1. Right Front of Engine Compartment




4. Behind Top Right Side of Radiator




2. Right Front of Engine Compartment, Behind Radiator




5. Right Rear of Engine, Below Air Cleaner



3. Right Front of Engine Compartment, Behind Radiator




6. Left Side of Engine




Ground Distribution


7. Left of Engine, on Left Side of Carburetor




10. Right Side of Engine Compartment, Rear of Battery




8. Right Front Corner of Engine Compartment, Behind Bumper




11. Right Front Corner of Engine Compartment, Front of Battery



9. Left Front of Engine Compartment, Behind Radiator






Distribution: G201


Circuit Schematic




Ground Distribution: G201

- Circuit Schematic







1. Under Left Side of Dash, Right of Steering Column




4. Under Console, at Base of Gear Selector



2. On Steering Column Trim Panel




3. Left Side of Dash, Behind I/P





Ground Distribution: G400 (Sedan and Coupe)

- Circuit Schematic




G401 (Hatchback)

- Circuit Schematic




Ground Distribution


1. Center of Trunk, Below Rear Deck




4. Under Carpet, on Left Rear Side of Rear Deck




2. Right Rear Corner of Trunk




5. Under Maintenance Access Cover, in Luggage Area




3. Right Rear of Hatch, Behind Access Panel




6. Center of Hatch, Behind End Panel




7. Left Center of Hatch




10. Left Rear Corner of Trunk



8. Center Rear of Trunk





9. Right Rear Corner of Trunk




Ground Distribution: G101 and G106

- Circuit Schematic







4 Door LX



4 Door DX Coupe DX




LX - California 4 Door
LXi - All Models
SEi - All States




All wires shown are black.

Ground Distribution


1. Rear of Right Inner Fender Panel




4. Under Left Front Seat




2. Bottom View of Under-hood Fuse Box




5. Top Left Side of Engine, Behind Valve Cover




3. Under Left Side of Dash, at Kick Panel




6. Right Side of Engine Compartment, Rear of Battery







7. Right Rear Corner of Engine Compartment




8. Right Side of Engine Compartment, on Inner Fender Panel



9. Top Right Center of Engine Compartment, at End of Cylinder Head





10. Left Inner Fender Panel, Forward of Strut Tower




Ground Distribution: G105 and G301

- Circuit Schematic







1. Top Right Front of Engine



4. Right Rear of Engine, on Air Cleaner



2. Right Front of Engine Compartment, Forward of Battery



3. Under Left Front Seat






Figure 1: Map of the study area showing the location of the study sites.




Figure 2: Map of the study area showing the location of the study sites.



Figure 3: Map of the study area showing the location of the study sites.



Figure 4: Map of the study area showing the location of the study sites.








Figure 1: Distribution: G200, G300 and G301

Figure 1: Distribution: G200, G300 and G301




Ground Distribution: G200, G300 and G301

- Circuit Schematic




All wires shown are black.




Ground Distribution


1. Inside Rear of Left Front Door




2. Top Center of Left Front Door




3. Front of Left Front Door




4. Under Left Front Seat




5. Under Left Side of Dash




6. Under Left Side of Dash, at Kick Panel







7. Under Left Side of Dash, at Kick Panel




8. Under Left Side of Dash, on Right Side of Dash Fuse Box




9. On Steering Column




10. Rear View of Dash Fuse Box



11. Beneath Dash, Near Speedometer Cable




12. Under Right Front Seat




Ground Distribution


13. Under passenger's Seat




16. Under Left Front Seat




14. Under Right Side of Dash, Behind Heater Assembly




17. Under Right Front Seat




15. Under Center of Dash




18. Under Right Side of Dash, Left of Steering Column







19. Center of Left Front Door




22. Rear of Right Door




20. Under Left Side of Dash, Below Steering Column




23. Rear Half of Driver's Door (Panel Removed)



21. Under Right Side of Dash, At Kick Panel




24. Rear Half of Driver's Door (Panel Removed)




Ground Distribution


25. Rear Half of Right Door (Panel Removed)




26. Under Right Side of Dash, at Kick Panel




27. Under Left Side of Dash







Circuit Diagram



Horn

- Circuit Schematic







How The Circuit Works

Voltage is applied through fuse 4 to the right and left horns. With any of the horn switches closed, ground is provided to the horns: The horns sound. The steering shaft is grounded to the steering column by a ground collar in the upper part of the column.


2. Bottom View of Under-hood Fuse Box




3. Right Front Corner of Engine Compartment, Behind Bumper



4. Left Front Corner of Engine Compartment, Behind Bumper




1. Right Side of Engine Compartment, on Inner Fender Panel




Horn


5. Top of Steering Column, Steering Wheel Removed



6. Under Left Side of Dash, on Right Side of Dash Fuse Box





7. Under Right Side of Dash, Behind Blower Assembly




8. Under Left Side of Dash, At Kick Panel






Headlights

- Circuit Schematic





How The Circuit Works

Lo Beam Operation

With the headlight switch in "Head," voltage is applied through the headlight switch, the dimmer/passing switch and fuses 6 and 7, to the "Lo" filaments of the dual beam headlights. The "Lo" filaments light up.


Hi Beam Operation

With the headlight switch in "Head" and the dimmer/passing switch in "High," voltage is applied through the headlight switch, the dimmer/passing switch, and fuses 8 and 9 to the "Hi" filaments of the dual beam headlights. Voltage is also applied to the high beam indicator.


Flash Operation

The flash feature works with the headlight switch in "Off," "Park," or "Head" (lo beams). With the dimmer/passing switch moved to "Flash," voltage is applied in the same way as in Hi Beam Operation except the headlights and high beam indicator flash to hi beams. The flash function has no effect if the dimmer/passing switch is in "High."


1. Right Side of Engine Compartment, on Inner Fender Panel




2. Under Left Side of Dash, Left of Steering Column



3. Rear View of Dash Fuse Box




4. Under Dash, Near Speedometer Connector




Headlights


5. Right Front Corner of Engine Compartment




6. Left Front Corner of Engine Compartment, Behind Headlight




8. Bottom View of Under-hood Fuse Box



9. Front View of Dash Fuse Box




7. Under Left Side of Dash, Right of Steering Column



10. Left Side of Dash, Behind I/P






End of Retractor: Controls

- Circuit Schematic



RETRACTOR



- Circuit Schematic



Motors



Headlight Retractors

How The Circuit Works

The headlights can be raised or retracted with the headlight motor switch on the instrument panel or with the light switch on the turn signal lever.

Headlight Motor Switch Operation


With the headlights retracted, the headlight switch in "Off," and the headlight motor switch pressed in (Raise), voltage is applied to the headlight retractor control unit, the left retractor motor "Up" contact, and the left retractor relay coil to ground. The relay operates and current flows through the relay contacts and left retractor motor to ground. The motor operates to raise the headlight. With the headlight fully raised, the left retractor motor "Up" contact opens and voltage to the left retractor relay is stopped. The relay moves to the position shown in the schematic and voltage to the motor is cut off: The motor stops. Similar operation occurs simultaneously for the right retractor relay and motor.

When the retractor relay contacts return to the de-energized state, ground is connected to both sides of the retractor motor. This acts as a dynamic brake to stop the motor quickly.


With the headlights raised, the headlight switch in "Off," and the headlight motor switch released (Retract), voltage is applied to the headlight motor switch, the headlight retractor control unit "Dn" contacts, the left retractor motor "Dn" contact, and the left retractor relay coil. The motor operates to retract the headlights. With the headlights fully retracted, the left retractor motor "Dn" contact opens and voltage to the left retractor relay is discontinued. The relay moves to the position shown in the schematic and voltage to the motor is cut off: The motor stops. Similar operation occurs simultaneously for the right retractor relay and motor.

Safety Indicator Operation


Voltage is applied to the headlight retractor control unit whenever the retractor relays operate to activate the retractor motors. The relays operate only for the short time it takes the headlights to rise or retract. With the headlights operating normally, the time that this voltage is applied to the timer is fixed and equal. If the voltage is applied for too long, not long enough or unequally, the timer sends a signal to the safety indicator. The safety indicator lights the headlight motor warning light symbol on the safety indicator panel to indicate a problem with the headlight retractors.




1. Under Left Side of Dash, Right of Steering Column




2. Under Left Side of Dash, at Kick Panel



3. Right Front of Engine Compartment, Right of Radiator




4. On Right Inner Fender Panel, Behind Headlight



5. Under Right Side of Dash, Behind Blower Assembly




6. On Left Inner Fender Panel, Behind Headlight




Headlight Retractors


7. Left Front Corner of Engine Compartment, Behind Headlight




8. Rear View of Dash Fuse Box




9. Bottom View of Under-hood Fuse Box




10. Under Left Side of Dash, Left of Steering Column




11. Right Side of Engine Compartment, on Inner Fender Panel




12. Front View of Dash Fuse Box








13. Under Dash, Near Speedometer Cable



Turn Signal and Hazard Lights

- Circuit Schematic





Turn Signal and Hazard Lights

How The Circuit Works

Turn Signal Operation


With the ignition switch in "Run" or "Start," and the turn signal switch in the "Left Turn" position, voltage is applied to the coil and flasher of the turn signal/hazard relay. The solid-state flasher provides a ground for the relay coil. The coil controls the relay contacts. As the flasher contacts open and close, the left turn signal lights and the left turn signal indicator flash.

With the turn signal switch in the "Right Turn" position, current follows a similar path through the right turn signal lights and indicator.


Hazard Flasher Operation

With the hazard switch in "On," voltage is always applied to the turn signal/hazard relay coil and flasher. The solid-state flasher provides a ground for the relay coil. The coil controls the relay contacts. As the flasher contacts open and close, all the turn signal lights and both indicators flash.


2. Rear View of Dash Fuse Box




3. Under Left Side of Dash, Left of Steering Column




1. Right Side of Engine Compartment, on Inner Fender Panel




4. Under Dash, Near Speedometer Connector







5. Under Left Side of Dash, on Right Side of Dash Fuse Box




6. Under Carpet, Next to Driver's Door




7. Under Left Side of Dash, Right of Steering Column




8. Bottom View of Under-hood Fuse Box



9. Left Front Corner of Engine Compartment, Behind Headlight



10. Right Front of Engine Compartment




Turn Signal and Hazard Lights


11. Left Side of Dash, Behind I/P




14. Front View of Dash Fuse Box




12. Under Left Side of Dash, Left of Steering Column




15. In Right Rear of Trunk Behind Panel




13. Under Carpet, on Left Rear Side of Rear Deck




16. Center Rear of Hatch, Behind End Panel







17. Behind Lower Left Corner of Bumper




18. Right Front Corner of Engine Compartment, Behind Bumper




19. Left Rear Corner of Trunk





20. Right Rear Corner of Trunk



- Circuit Schematic





Parking, Hazard and Front Marker Lights

How The Circuit Works

With the headlight switch in "Park" or "Head," voltage is applied to the side marker control unit (part of the integrated control unit) and the parking lights: The parking lights go on. The side marker control unit contacts close and the front side marker lights go on.

Turn Operation

With the ignition switch in "Run" or "Start," and the turn signal switch in "Left Turn," voltage is applied to the coil and flasher of the turn signal/hazard relay. The solid-state flasher provides a ground for the relay coil. The coil controls the relay contacts. As the flasher contacts open and close, the side marker control unit receives an on-off voltage which causes the left front side marker light to flash.

The right front side marker light operates the same way.


With the headlight switch in "Off," the front side marker lights flash simultaneously with the front and rear turn signal lights.

With the headlight switch in "Head" or "Park," the front side marker lights and the turn signal lights flash alternately.


Hazard Operation

With the hazard switch "On," voltage is always applied to the turn signal/hazard relay. Hazard operation is similar to turn operation, except both the right and left front side marker lights flash simultaneously.


1. Right Side of Engine Compartment, on Inner Fender Panel




2. Front View of Dash Fuse Box




3. Under Left Side of Dash, Left of Steering Column







4. Under Dash, Near Speedometer Connector




5. Under Left Side of Dash, on Right Side of Dash Fuse Box




6. Right Front Corner of Engine Compartment, Behind Bumper




7. Left Front Corner of Engine Compartment, Behind Bumper



8. Left Front Corner of Engine Compartment, Behind Headlight




9. Right Front of Engine Compartment




Parking, Hazard, and Front Side Marker Lights


10. Under Center of Dash




13. Bottom View of Under-hood Fuse Box



11. Under Left Side of Dash, Left of Steering Column




14. Rear View of Dash Fuse Box



12. Under Right Side of Dash, Below Blower Assembly




15. Under Left Side of Dash, at Kick Panel





Brake Lights - Circuit Schematic





How The Circuit Works

Brake Lights

With the brake light switch closed, voltage is applied through the cruise control switch and the brake light sensor coils to the brake light filaments: The brake lights go on. The brake light sensor coils offer very little resistance to the brake light current.


Safety Indicator Input

If the safety indicator senses a burned out brake light filament, it lights up the "Brake Lamp" symbol on the safety indicator panel. Terminal 6 of the safety indicator senses ground through the brake light sensors and brake light filaments. With the brake switch open (brake lights off), terminal 6 of the safety indicator senses ground through any of the five brake light sensor coils and brake light filaments. The indicator does not light up the "Brake Lamp" symbol.


When the brake switch is closed (brake lights on), current through the brake light sensor coils and brake lights to ground closes the brake light sensor contacts. Terminal 6 of the safety indicator is then grounded through the brake light sensor contacts. If all five brake light filaments are good, terminal 6 senses ground through the five sensor contacts. The safety indicator does not light up the "Brake Lamp" symbol.

If any one of the five brake light filaments is burned out, the brake light sensor coil for that filament does not receive ground, so its contacts remain open. With the contacts open, terminal 6 of the safety indicator does not sense ground so the indicator lights up the "Brake Lamp" symbol on the safety indicator panel. The symbol remains on until the ignition switch is turned off.


1. Under Carpet, in Left Rear Side of Rear Deck



2. Left Rear Corner of Trunk




3. Under Carpet, Next to Driver's Door




Brake Lights


4. Under Left Side of Dash, Right of Steering Column



7. Under Left Side of Dash, Left of Steering Column




5. Right Rear Corner of Trunk




8. Behind Right Side of Dash, Near Interior Grommet




6. Center of Trunk, Below Rear Deck




9. Rear View of Dash Fuse Box







10. Bottom View of Under-hood Fuse Box




13. Center Rear of Hatch, Behind End Panel




11. Under Left Side of Dash, Left of Steering Column




14. Rear Right Corner of Trunk




12. Right Side of Engine Compartment, on Inner Fender Panel



–Circuit Schematic







How The Circuit Works

Voltage is applied through fuse 19 to the headlight switch at all times. With the headlight switch in "Park" or "Head," voltage is applied to the tail, rear side marker, and license plate lights: The lights go on.


1. Under Carpet, in Left Rear Side of Rear Deck




2. Right Rear Corner of Trunk




3. Left Rear Corner of Trunk



4. Under Carpet, Next to Driver's Door




5. Bottom View of Under-hood Fuse Box




Tail and License Plate Lights


6. Front View of Dash Fuse Box




7. Right Side of Engine Compartment, on Inner Fender Panel




8. Under Left Side of Dash, Left of Steering Column




9. Right Rear Corner of Trunk




10. Rear View of Dash Fuse Box




11. Center Rear of Hatch, Behind End Panel







Circuit Schematic



Back Up Lights

- Circuit Schematic







How The Circuit Works

With the ignition switch in "Run" or "Start," voltage is applied through fuse 2 to the neutral safety/back up lights switch (with automatic transmission), or to the back up lights switch (with manual transmission). When you shift the gear selector lever to "Reverse", the neutral safety/back up lights switch or the back up lights switch closes and voltage is applied to the back up lights: The back up lights go on.


1. In Console, at Base of Gear Selector




2. Right Front Corner of Engine Compartment, Front of Battery




3. Under Carpet, Next to Driver's Door



4. Under Carpet, on Left Rear Side of Rear Deck




5. Rear View of Dash Fuse Box




Back Up Lights


6. Under Left Side of Dash, Left of Steering Column




9. Under Dash, Right of Heater Assembly




7. Under Left Side of Dash, at Kick Panel




10. Right Rear Corner of Trunk




8. Center Rear of Hatch, Behind End Panel



11. Left Rear Corner of Trunk







Bed and Console Lights Circuit Schematic



- Circuit Schematic







(cont'd)

Dash and Console Lights

- Circuit Schematic (cont'd)






How The Circuit Works


Except for the ashtray, glove box, clock, and radio lights, all dash and console lights can be dimmed. The ashtray, glove box, clock, and radio lights are at full brightness any time the headlight switch is in "Off." With the headlight switch in "Park" or "Head," the lights are dimmed one step.

The dash lights dimmer, which is a variable resistor, and the dimmer control amplifier vary the brightness of the console lights.


1. Under Carpet, Next to Driver's Door




2. Under Left Side of Dash, Right of Steering Column



3. Right Front of Trunk, Near Speaker



4. Behind Right Side of Dash, Behind Glove Box




5. Behind Right Side of Dash, Below Blower Assembly




Dash and Console Lights


6. On Steering Column Trim Panel




7. In Console, at Base of Gear Selector




9. Front View of Dash Fuse Box




10. Right Side of Engine Compartment, on Inner Fender Panel




8. Bottom View of Under-hood Fuse Box




11. Under Left Side of Dash, Left of Steering Column







12. Rear View of Dash Fuse Box



15. Left Side of Dash, Behind I/P



13. Top Left Front of Trunk





14. Behind Front of Cigarette Lighter



Door Courtesy Lights

- Circuit Schematic







How The Circuit Works

Voltage is applied at all times to all of the door courtesy lights. When you open a door, the door switch closes. Current flows through the fuse and the door courtesy light to ground: The door courtesy light goes on.


1. Under Right Side of Dash, Behind Blower Assembly



2. In Right Center Pillar, Between Front and Rear Doors




3. Under Carpet, Next to Driver's Seat



4. In Left Center Pillar, Between Front and Rear Doors




5. Bottom View of Under-hood Fuse Box




Door Courtesy Lights


6. Right Side of Engine Compartment, on Inner Fender Panel




7. Under Left Side of Dash, Left of Steering Column




8. Under Left Side of Dash, at Kick Panel






Circuit Schematic



Indicator, Interior, and Trunk/Hatch Lights



Safety Indicator, Interior, and Trunk/Hatch Lights

- Circuit Schematic





Safety Indicator, Interior, and Trunk/Hatch Lights

How The Circuit Works

Safety Indicator and Trunk/Hatch Light

With the ignition switch in "Run" or "Start," voltage is applied to the YEL wire terminal of the safety indicator. The brightness of the safety indicator display is controlled by the dash lights dimmer when the headlight switch is in "Park" or "Head."


When you open the trunk or hatch lid, the trunk or hatch light switch closes and turns on the trunk/hatch light: The GRN/BLK wire terminal of the safety indicator senses ground and the indicator lights the trunk/hatch symbol on the indicator panel.

When you open the driver's door, the door switch closes, providing a ground to the interior light, which is sensed by the GRN/BLU wire terminal of the safety indicator. The indicator lights up the driver's door symbol on the indicator panel. If the light switch is in the "Door" position, the interior light will go on. The other door switches work the same way.


Brake Light Bulb Failure Warning

For information on how the safety indicator works in this circuit, see the Brake Lights circuit.


1. Under Carpet, Next to Driver's Door




2. Under Left Side of Dash, Right of Steering Column




3. Rear of Car, Near Trunk Latch Mechanism







4. Under Carpet, in Left Rear Side of Rear Deck




7. Bottom View of Under-hood Fuse Box




5. Right Front of Trunk, Near Speaker




8. Center Rear of Hatch, Behind End Panel



6. Rear View of Dash Fuse Box




9. Under Left Side of Dash, at Kick Panel




Safety Indicators, Interior, and Trunk/Hatch Lights



10. Right Side of Engine Compartment




11. Upper Left Front of Trunk, Near Speaker




12. Left Side of Dash, Behind I/P






Clock and Cigarette Lighter

- Circuit Schematic







How The Circuit Works

Voltage is applied at all times through fuse 11 to provide memory for the clock. With the ignition switch in "Run" or "Start," voltage is applied through fuse 2 to provide for the clock display. Voltage is applied at all times to the cigarette lighter.


1. Under Left Side of Dash, Right of Steering Column




2. Rear View of Dash Fuse Box




3. Bottom View of Under-hood Fuse Box



4. Under Left Side of Dash, Left of Steering Column




5. Behind Front Cigarette Lighter



Clock and Cigarette Lighter


6. Under-Hood Fuse Box






Oil and Key Warning, and Ignition Key Light


Oil and Key Warning, and Ignition Key Light



Seat Belt and Key Warning, and Ignition Key Light

- Circuit Schematic





How The Circuit Works

Seat Belt Warning

With the ignition switch in "Run" or "Start," voltage is applied to the seat belt/key timer-buzzer (part of integrated control unit). When you unbuckle the driver's seat belt, the seat belt/key timer-buzzer senses ground. With voltage and ground, the seat belt buzzer sounds and the timer contacts close and open. This causes the seat belt warning indicator light to flash on and off. After 5 seconds, the alarm stops and the contacts remain open.


Key Warning

When the key switch is closed, ground is provided for the seat belt/key timer-buzzer (part of integrated control unit). When you open the driver's door or right door, the key buzzer senses ground through the closed door switch: The key buzzer sounds.


Key Light

Voltage is applied to the key light at all times. When the driver's door is opened, ground is provided to the key light timer circuit (part of integrated control unit). The timer provides ground to the key light for approximately 8 to 10 seconds.


2. Under Center of Dash




3. Under Dash, Near Speedometer Connector



1. Under Left Side of Dash, Right of Steering Column




4. In Console, at Base of Parking Brake




Seat Belt and Key Warning, and Ignition Key Light


5. Under Left Front Seat




8. Bottom View of Under-hood Fuse Box




6. Under Left Side of Dash, Below Steering Column




9. Under Left Side of Dash, Left of Steering Column




7. Rear View of Dash Fuse Box




10. Right Side of Engine Compartment, on Inner Fender Panel







11. On Steering Column



12. Under Left Side of Dash, at Kick Panel





13. Under Left Side of Dash



Brake Warning System

- Circuit Schematic





How The Circuit Works

The brake warning indicator light goes on if the parking brake is applied, if the brake fluid level is low, and as a bulb test while cranking the engine.

Parking Brake

With the ignition switch in "Run" or "Start," and the parking brake switch closed, the brake warning indicator light operates to remind the driver that the parking brake is applied.


Brake Fluid Level

With the ignition switch in "Run" or "Start," and the brake fluid level switch closed, the brake warning indicator light operates to warn the driver of low brake fluid level in the brake master cylinder. (Note: Check brake pad wear before adding fluid.)


Bulb Check

With the ignition switch in "Start," voltage is applied through fuse 10 to the bulb check unit of the warning display. The bulb check unit contacts close, and current flows through the brake warning indicator light and bulb check unit contacts to ground: The brake warning indicator light goes on to test the brake warning indicator light bulb.


1. Under Left Side of Dash, Right of Steering Column



2. Left Rear Corner of Engine Compartment




3. Left Front Corner of Engine Compartment, Behind Headlight



Brake Warning System



4. Rear View of Dash Fuse Box




7. Left Side of Dash, Behind I/P




5. Under Left Side of Dash, Left of Steering Column






Auto Warning System


Control System



Oil Pressure Warning System

- Circuit Schematic





How The Circuit Works


The oil pressure warning indicator light works in two ways. It flashes continuously following a momentary loss of oil pressure, or it goes on with a complete loss of oil pressure.

When the engine first starts, before oil pressure rises above 4.2 psi, voltage is applied through the oil pressure warning indicator light and the oil pressure switch to ground. This tests the bulb.


With the engine running, voltage is applied to the oil flasher unit (part of the integrated control unit). With normal oil pressure, the oil pressure switch is open and the oil pressure warning indicator light does not go on. If the oil pressure switch closes momentarily (more than 0.5 seconds), but then opens again, the oil flasher unit senses ground through the switch. The oil flasher unit then provides and removes ground for the oil pressure warning indicator light. The light flashes on and off until the ignition switch is turned off. The flashing feature will not work until 30 seconds after initial voltage is applied to the oil flasher unit. This delay avoids unnecessary warning indicator light operation.

If engine oil pressure falls below 4.2 psi and does not increase, the oil pressure switch will stay closed. The oil pressure warning indicator light goes on and stays on.


1. Under Left Side of Dash, Right of Steering Column



2. Right Front Corner of Engine Compartment, Forward of Battery




3. Under Center of Dash




Oil Pressure Warning System


4. Under Dash, Near Speedometer Connector




5. Rear View of Dash Fuse Box




6. Under Left Side of Dash, Left of Steering Column




7. Lower Left Rear of Engine




8. Lower Left Center of Engine, Front of Oil Filter



9. Under Left Side of Dash, at Kick Panel







On Warning

Current Schematic



- Circuit Schematic







How The Circuit Works

With the headlight switch in "Park" or "Head" and the ignition switch in "Run" or "Start," voltage is applied to the Lights On Warning circuit. This prevents the Lights On Warning circuit from applying voltage to the lights-on warning chime, and the chime does not sound (lights and ignition on with driver's door closed). When the ignition switch is turned off (key removed), and the driver's door is opened while the lights are on, voltage pulses are applied to the lights-on warning chime. The chime sounds to remind the driver to turn off the lights.

2. Under Center of Dash




3. Under Left Side of Dash, Right of Steering Column



1. Under Right Side of Dash, Behind Blower Assembly




4. On Steering Column Trim Panel




Lights On Warning


5. Beneath Dash, Near Speedometer Connector




8. Under Left Side of Dash, Left of Steering Column




6. Rear View of Dash Fuse Box




9. Right Side of Engine Compartment, on Inner Fender Panel




7. Bottom View of Under-hood Fuse Box




10. Front View of Dash Fuse Box







Low Fuel Warning System



Warning Indicators and Low Fuel Warning System

- Circuit Schematic





How The Circuit Works

Oil Pressure Warning Indicator Light

For the oil pressure warning indicator light, see the Oil Pressure Warning System circuit.

Seat Belt Warning Indicator Light

For the seat belt warning indicator light, see the Seat Belt and Key Warning System circuit.

Charge Indicator Light

For the charge indicator light, see the Charging System circuit.

Cruise Control On Indicator Light

For the cruise control on indicator light, see the Cruise Control circuit.

PGM-FI Indicator Light

For the PGM-FI indicator light, see the Electronic Fuel Injection circuit.


Brake Warning Indicator Light

For the brake warning indicator light, see the Brake Warning System circuit.


Low Fuel Warning System

The thermistor is mounted in the fuel tank, as part of the fuel gauge sender. When the thermistor is cool, its resistance is very high. When the thermistor is warm, its resistance lowers. Fuel in the fuel tank transfers heat away from the thermistor fast enough to keep it cool. The thermistor resistance stays high and the low fuel warning light does not operate. When the fuel level drops below about 2.6 gallons, the thermistor is no longer immersed in fuel. Without the fuel to cool it, the thermistor resistance becomes low. Current flows through the low fuel warning light and the thermistor to ground. The low fuel warning indicator lights up.


1. Under Left Side of Dash, Right of Steering Column



2. Under Carpet, Next to Driver's Door




3. Under Carpet, on Left Rear Side of Rear Deck




Warning Indicators and Low Fuel Warning System


4. Rear View of Dash Fuse Box




5. Under Left Side of Dash, Left of Steering Column




6. Under Left Side of Dash, on Right Side of Dash Fuse Box




7. Under Left Side of Dash, at Kick Panel




8. Under Right Maintenance Access Cover in Luggage Area




9. Center Rear of Hatch, Behind End Panel






10. Left Side of Dash, Behind I/P





11. Under Driver's Seat



Shift Position Indicator

- Circuit Schematic






How The Circuit Works


With the ignition switch in "Run" or "Start," voltage is applied to the power terminal of the shift indicator panel. The gear selector switch provides a separate ground for each position. As an input is grounded, its indicator lights up. If "R" is selected, for example, a ground will be applied to the "R" input of the shift indicator panel, and the "R" indicator will light up.

With the headlight switch in "Park" or "Head," voltage is applied to the RED/BLK wire terminal. This changes indicator panel illumination from fixed to controlled by the dash lights dimmer.


2. Under Left Side of Dash, Right of Steering Column




3. Rear View of Dash Fuse Box



1. In Console, at Base of Gear Selector





4. Under Left Side of Dash, Left of Steering Column



Coolant Temperature and Fuel Gauges

- Circuit Schematic







How The Circuit Works

The coolant temperature gauge and the fuel gauge are each operated by two intersecting coils wound around a permanent magnet rotor. When voltage from fuse 1 is applied to the coils, a magnetic field is generated. This causes the rotor to rotate and the gauge needle to move. The magnetic field is controlled by the sender. As the resistance in the sender varies, current through the gauge coils changes. The gauge needle moves according to the changing magnetic field.


1. Rear View of Dash Fuse Box




2. Under Left Side of Dash, Right of Steering Column




3. Right Front Corner of Engine Compartment, Front of Battery



4. Center Rear of Hatch, Behind End Panel




5. Under Carpet, Next to Driver's Door




Coolant Temperature and Fuel Gauges


6. Under Carpet, on Left Rear Side of Rear Deck



9. Under Right Maintenance Access Cover in Luggage Area




7. Under Left Side of Dash, Left of Steering Column




10. Left Side of Dash, Behind I/P




8. Rear Center of Engine Compartment at End of Cylinder Head




11. Right Rear Corner of Engine Compartment, on Strut Tower







Circuit Schematic



Tachometer

- Circuit Schematic







How The Circuit Works

With the engine running, the tachometer senses ignition pulses from the distributor. The solid-state tachometer displays these pulses as engine speed.


1. Under Left Side of Dash, Right of Steering Column




2. Right Rear of Engine Compartment, Above Strut Tower




3. Right Side of Engine



4. Under Left Side of Dash, Left of Steering Column








5. Rear View of Dash Fuse Box




Tachometer

6. Left Side of Dash, Behind I/P







Circuit Schematic



- Circuit Schematic







How The Circuit Works

With the ignition switch in "Acc" or "Run," voltage is applied through fuse 13 to the radio on-off switch. When you turn the switch "On," current flows through these fuses into the receiver circuits. The WHT/YEL wire from fuse 11 provides a memory input to the radio.


2. Under Carpet, Next to Driver's Door




3. Under Right Side of Dash, Behind Blower Assembly



1. Under Left Side of Dash, Right of Steering Column




4. Rear View of Dash Fuse Box




Radio


5. Bottom View of Under-hood Fuse Box




6. Under Left Side of Dash, Left of Steering Column




7. Right Side of Engine Compartment, on Inner Fender Panel






Power Antenna

- Circuit Schematic







How The Circuit Works

With the ignition switch in "Acc" or "Run," voltage is applied to the antenna switch. The antenna motor will move the antenna completely up or completely down. The direction the motor turns depends on the polarity of the supply voltage.


3. Under Left Side of Dash, Left of Steering Column




1. Under Right Front Seat



4. Under Left Side of Dash, at Kick Panel




2. Rear View of Dash Fuse Box




Power Windows: Driver's Door

- Circuit Schematic









Power Windows

How The Circuit Works

The operation of the power windows is controlled by the main switch in the driver's power window master switch. When the main switch is in the "Off" position, only the driver's door window can be opened or closed. With the main switch in "On," each window can be opened or closed by the driver's power window master switch or by the window's respective switch. The driver's window also has an automatic "down" mode which is controlled at the driver's power window master switch.

Driver's Window


With the ignition switch in "Run" or "Start," and the driver's switch in "Up," voltage is applied through the closed contacts of the power window relay to the power window control unit. The control unit applies voltage to the driver's power window motor. The motor contacts close and will stay closed until the driver's switch is moved from "Up" to "Off" or the window goes completely up. After the window goes completely up, the contacts open and the motor stops. This prevents the motor from overheating if the switch is held in the "Up" position after the window has gone completely up. In "Down," current flows through the motor in the opposite direction.

Automatic Down (Driver's Window)


With the ignition switch in "Run" or "Start," voltage is applied to the coil of the power window relay. The contacts of the power window relay close and voltage is applied to the driver's power window master switch and the power window control unit. With the driver's switch pushed to the automatic down position, voltage is applied through the driver's switch to the power window control unit's down and down hold inputs. The driver's power window motor contacts close and current flows through the motor to ground. The motor runs and the window goes completely down. When the window reaches the completely down position, the driver's power window motor contacts open and the motor stops.

Passenger's Window


With the ignition switch in "Run" or "Start," voltage is applied to the coil of the power window relay. The contacts of the power window relay close and voltage is applied through fuse 18 to the right power window switch. With the main switch in "On" and the right front power window switch in "Up," current flows through the 45 amp fuse, the contacts of the power window relay, fuse 15, the "Up" contacts of the window switch, the right power window motor, back through the right front power window switch, and the driver's power window master switch to ground. The motor runs and the window goes up. In "Down," current flows through the motor in the opposite direction. The left and right rear power window switches operate similarly.




1. Rear of Right Inner Fender Panel




4. Beneath Dash, Near Speedometer Connector




2. Center of Left Front Door




5. Front of Right Front Door



3. Front of Left Front Door




6. Under Right Side of Dash, Behind Blower Assembly




Power Windows

7. Front of Right Rear Door




10. In Right Center Pillar, Between Front and Rear Doors




8. Front of Right Rear Door




11. Front of Left Rear Door




9. Under Left Side of Dash, at Kick Panel




12. Front of Left Rear Door







13. In Left Center Pillar, Between Front and Rear Doors




16. Front of Right Front Door




14. Rear View of Dash Fuse Box




17. Right Side of Engine Compartment, on Inner Fender Panel



15. Bottom View of Under-hood Fuse Box





18. Under Left Side of Dash, Left of Steering Column




Power

19. Front of Driver's Door






Door Locks - Circuit Schematic



Power Door Locks

- Circuit Schematic






Power Door Locks


How The Circuit Works

With all the doors locked, the driver's door and the right front door can be unlocked mechanically from the outside with the key. The master door lock switch will simultaneously lock or unlock all of the door locks. The passenger doors will also automatically lock when the driver's tab, on the driver's door, is pushed down. The driver's key door lock switch will automatically lock all doors when turned to the "Lock" position, but will only unlock the driver's door.


2. Under Right Front Seat




3. Under Left Side of Dash, Near Kick Panel



1. Bottom View of Under-hood Fuse Box




4. Top Center of Left Front Door






5. Rear of Left Front Door




6. Under Left Side of Dash, on Top of Steering Support Bracket




7. Under Right Side of Dash, Behind Blower Assembly




8. In Left Center Pillar, Between Front and Rear Doors



9. Rear of Left Rear Door




10. Rear of Right Rear Door




Power Door Locks


11. Rear of Right Front Door




12. In Right Center Pillar, Between Front and Rear Doors




13. Under Right Front Seat



14. Right Side of Engine Compartment, on Inner Fender Panel




15. Under Left Side of Dash, Left of Steering Column






Power Mirrors

- Circuit Schematic






How The Circuit Works


The operation of the two outside mirrors is controlled by the power mirror control switch. Each mirror has two reversible motors. One motor moves the mirror up and down; the other motor moves the mirror left and right. The power mirror control switch directs voltage to the right and left outside mirrors.

With the ignition switch in "Run," the master selector switch in "Left," and the up/down switch in "Up," voltage is applied through the "Up" contacts of the up/down switch to the left power mirror up/down motor. Ground is provided through the "Left" contacts of the master selector switch and the "Up" contacts of the up/down switch: The mirror goes up. In the "Down" position, voltage is applied to the opposite side of the motor.


1. Under Left Side of Dash, on Right Side of Dash Fuse Box




2. Under Left Side of Dash, Right of Steering Column



3. Left Front Door, Above Speaker




4. Right Front Door, Above Speaker



Power Mirrors


5. Left Side of Dash, Behind I/P




8. Below Right Side of Dash, at Kick Panel




6. Rear View of Dash Fuse Box




7. Under Left Side of Dash, Left of Steering Column







Washer Circuit Schematic



Wiper/Washer - Circuit Schematic





How The Circuit Works

Wiper Lo and Hi Operation

With the ignition switch in "Run" or "Start," and the wiper switch in "Lo," current flows through the wiper motor low brush and the wiper switch "Lo" contact to ground. The wiper motor operates at low speed.


When you move the wiper switch from "Lo" to "Off," current flows through the wiper motor, wiper switch "Off/Int" contacts, and wiper motor "Run" contacts to ground. The motor operates until the wiper blades reach the parked position. With the wiper blades parked, the wiper motor contacts move to "Park." Ground for the wiper motor is removed and the motor stops.

Similar current flow takes place with the wiper switch in "Hi."


Wiper/Int Operation

With the wiper switches in "Int," voltage is applied to terminal B of the timer relay, and the timer relay contacts operate. Current flows through the wiper motor, wiper switch "Off/Int" contacts, and timer relay contacts to ground. The wiper motor operates. Once the wiper motor starts, the wiper motor contacts move to "Run." The motor receives ground and the timer relay senses ground through the contacts. With ground at terminal D of the timer relay, the timer relay contacts move back to the position shown in the schematic. The motor operates as described in Wiper Lo and Hi Operation (above) until the wiper blades park. After a pause, the timer relay repeats this operation, making the wiper blades operate intermittently.


1. Behind Lower Left Corner of Bumper



2. Under Dash, Near Speedometer Cable




3. Left Rear of Engine Compartment, Behind Strut Tower




Wiper/Washer


4. Left Front Corner of Engine Compartment, Behind Headlight




7. Under Left Side of Dash, on Right Side of Dash Fuse Box




5. Rear View of Dash Fuse Box




8. Front View of Dash Fuse Box





6. Under Left Side of Dash, Left of Steering Column




9. Under Left Side of Dash, Left of Steering Column






Rear Wiper/Washer

- Circuit Schematic






How The Circuit Works

With the ignition switch in "Run" or "Start," and the rear wiper switch in the "On" position, voltage is applied to the rear wiper motor. The rear wiper motor operates.


When you move the rear wiper switch from "On" to "Off," current flows through the rear wiper motor, the "Off" contacts of the rear wiper switch, and the rear wiper motor "Run" contacts to ground. The motor operates until the wiper blades reach the parked position. When the wiper blades are parked, the rear wiper motor contacts move to "Park." Ground for the rear wiper motor is removed and the motor stops.

With the ignition switch in "Run" or "Start," and the washer switch pushed to "On," voltage is applied to the rear washer motor. The motor operates.


1. Under Dash, Near Speedometer Cable




2. Left Front Corner of Engine Compartment, Behind Headlight



3. Under Carpet, Next to Driver's Door




4. Under Left Side of Dash, on Right Side of Dash Fuse Box




Rear Wiper/Washer


5. Under Left Side of Dash, Left of Steering Column




8. Front View of Dash Fuse Box




6. Rear View of Dash Fuse Box




9. Under Left Side of Dash, Left of Steering Column




7. Left Center of Hatch




10. Right Rear of Hatch, Behind Access Panel






11. Behind Lower Left Corner of Bumper





12. Center Rear of Hatch, Behind End Panel



Rear Window Defogger

- Circuit Schematic






How The Circuit Works

The defogger operates when voltage is applied to the defogger grid on the surface of the rear window. The grid heats the back window to remove interior fog from the glass.


When you turn the defogger switch in "On", two things happen: The "Defogger On" indicator lights up and the defogger operates. With the ignition switch in "Run," voltage is applied to the coil of the defogger relay and the indicator light. When the rear defogger switch is pushed, a ground is provided for the relay coil and the indicator light. The relay contacts close and apply voltage to the defogger grid: The grid heats up and the indicator light goes on.




1. Under Left Side of Dash, Right of Steering Column




2. Under Carpet, Next to Driver's Seat



3. Under Left Side of Dash, Left of Steering Column




4. Under Carpet, in Right Rear Side of Rear Deck




Rear Window Defogger


5. Rear View of Dash Fuse Box




6. Bottom View of Under-hood Fuse Box




7. Under Left Side of Dash, Left of Steering Column




8. Right Side of Engine Compartment, on Inner Fender Panel





9. Right Rear of Hatch, Behind Access Panel




10. Center Rear of Hatch, Behind End Panel






Sunroof

- Circuit Schematic







How The Circuit Works

With the ignition switch in "Run" or "Start," voltage is applied to each relay coil. When the sunroof switch is moved to open the sunroof, a path to ground is provided for the sunroof (open) relay coil. The relay contacts close and voltage is applied to the sunroof motor. Ground for the motor is provided through the contacts of the sunroof (close) relay. The sunroof motor operates to open the sunroof. When the sunroof switch is moved to close the sunroof, the current path is reversed and the motor operates in the reverse direction.

1. Under Right Front Seat




2. Right Front of Trunk, Near Speaker.




3. Under Right Side of Dash, Behind Blower Assembly



4. Under Left Side of Dash, on Right Side of Dash Fuse Box




5. Rear View of Dash Fuse Box




Sunroof


6. Under Left Side of Dash, Right of Steering Column




7. Under Left Side of Dash, Left of Steering Column



8. Bottom View of Under-hood Fuse Box




9. Right Side of Engine Compartment, on Inner Fender Panel




10. Left Side of Dash, Behind I/P




11. Rear of Ceiling, above Headliner







12. Left Rear of Ceiling, above Headliner



Blower

- Circuit Schematic





How The Circuit Works

The blower switch regulates the speed of the four speed blower motor. The switch can be set to "Lo," "Med 1," "Med 2," or "Hi."

The position of the blower switch determines the path to ground for the current flowing through the blower motor. With the switch in "Lo," three resistors are included in the circuit. With the switch in "Med 1," two resistors are included in the circuit. With the switch in "Med 2," one resistor is included in the circuit. The resistors drop a portion of the circuit voltage, slowing the motor speed. With the switch set to "Hi," no resistors are included in the circuit. Most of the circuit voltage is dropped across the motor, causing it to run at high speed.

Lo Setting

With the ignition switch in "Run," voltage is applied through the fuse to the blower motor. With the blower switch set to "Lo," current flows through the blower motor, all of the blower resistors and the "Lo" contacts of the blower switch to ground. The motor runs at the slowest speed.


Med and Hi Settings

With the ignition switch in "Run," voltage is applied through fuse 22 to the blower motor. With the blower switch set to "Med 1," current flows through the fuse, the blower motor, two blower resistors, and the "Med 1" contacts of the blower switch to ground. The motor runs at low speed.


When you set the blower switch to "Med 2," current flows through the fuse, the blower motor, one blower resistor, and the "Med 2" contacts of the blower switch to ground. The motor runs at medium speed.

When you set the blower switch to "Hi," current flows through the fuse, the blower motor, and the "Hi" contacts of the blower switch to ground. The motor runs at high speed.


1. Bottom View of Under-hood Fuse Box



2. Under Left Side of Dash, Left of Steering Column




3. Front View of Dash Fuse Box




Blower


4. Under Right Side of Dash, at Kick Panel




5. Top Right Side of Steering Column




6. Under Left Side of Dash, Right of Steering Column




7. Rear View of Dash Fuse Box




8. Right Side of Engine Compartment, on Inner Fender Panel




9. Under Left Side of Dash, Left of Steering Column








Start Controls Circuit Schematic



Heater Controls

- Circuit Schematic






Heater Controls

How The Circuit Works

The heating and ventilating system has five modes: "Vent," "Hi-Lo," "Heat," "H/Def," and "Def." In addition to the five modes, you can shut off the air or change the air the system uses (from fresh to recirculated) by using the Rec and Fresh switch.


1. Under Left Side of Dash, Right of Steering Column




3. Left Side of Dash, Behind I/P




4. Under Left Side of Dash, Right of Steering Column




2. Under Right Side of Dash, at Kick Panel




5. Under Left Side of Dash, on Top of Steering Column Support






6. Rear View of Dash Fuse Box






7. Under Left Side of Dash, Left of Steering Column



Fans and Air Conditioner (Carb)



- Circuit Schematic





- Circuit Schematic





Fans and Air Conditioner

How The Circuit Works

Radiator and Condenser Fans

The radiator fan motor operates with the ignition switch in "Run" and the temperature of the coolant in the radiator above 90 degrees C (194 degrees F). If the car is equipped with air conditioning, the radiator fan motor and the A/C condenser fan motor both operate with the coolant above 90 degrees C (194 degrees F) or with the A/C compressor clutch engaged. With the coolant above 90 degrees C (194 degrees F), voltage is applied to the radiator fan relay coil and the radiator fan temperature switch to ground. The relay contacts close and voltage is applied to the radiator fan motor: The motor operates.

With the A/C switch on the heater control panel closed and the blower switch on, voltage is applied to the radiator fan relay coil, the A/C diode box, the A/C pressure cutout switch, the A/C thermostat, and the A/C switch to ground. The radiator fan relay contacts close. Voltage is then applied to the relay and both the radiator and A/C condenser fans to ground.

Air Conditioning Compressor

With the A/C switch on the heater control panel closed, voltage is applied to the A/C compressor clutch relay, the A/C delay unit, the A/C compressor clutch relay, the A/C diode unit, the A/C diode box, the A/C pressure cutout switch, the A/C thermostat, and the A/C switch to ground. The A/C compressor clutch relay contacts close, and voltage is applied to the A/C compressor clutch. After a .5 second delay, the A/C compressor clutch comes on.

The contacts in the delay relay close and the emission control unit signals the idle control solenoid. This solenoid increases the engine idle speed to compensate for the extra load of the A/C compressor.

The solid-state controlled contacts close .5 seconds after the delay relay coil is energized. Voltage is applied to the A/C compressor clutch relay coil and the solid-state controlled contacts of the delay relay to ground.


A/C system pressure below 206 kPa (28 psi) indicates a loss of refrigerant or refrigerant oil. The A/C pressure cutout switch opens with system pressure below 206 kPa (28 psi) to prevent compressor damage from loss of refrigerant.

The A/C thermostat senses evaporator temperature. With the evaporator temperature above 5 degrees C (41 degrees F), the switch closes to activate the A/C compressor clutch. With the evaporator temperature below 1 degree C (33 degrees F), the compressor cycling switch opens. In this way, the evaporator temperature stays above 1 degree C (33 degrees F) and moisture on the evaporator fins does not freeze and block air flow.


The diodes in the A/C diode box prevent operation of the compressor when the radiator fan temperature switch closes.




1. Under Right Front Seat (EFI)




2. Left Front of Engine Compartment, Below Power Steering Reservoir



3. Left Front of Engine Compartment, Behind Radiator



4. Right Front of Engine Compartment, Behind Radiator



5. Left Side of Dash, Behind I/P



6. Right Front of Engine Compartment, Behind Radiator




Fans and Air Conditioner


7. Under Right Side of Dash, Behind Blower Assembly




10. Under Left Side of Dash, at Kick Panel




8. On Right Inner Fender Panel, Behind Headlight




11. Right Rear of Engine Compartment, Above Strut Tower




9. Under Left Side of Dash, Right of Steering Column




12. Left Side of Engine Compartment, Left of Radiator







13. Beneath Dash, Near Speedometer Connector




14. Lower Left Front of Engine Compartment, Left of Radiator




15. Left Front of Engine Compartment, Behind Headlight




16. Right Center of Dash, on A/C Evaporator



17. Rear View of Dash Fuse Box




18. Bottom View of Under-hood Fuse Box




Fans and Air Conditioner


19. Under Left Side of Dash, Left of Steering Column




22. Top Left Side of Engine, Behind Valve Cover




20. Right Side of Engine Compartment, on Inner Fender Panel




23. Under Right Front Seat




21. Left Side of Engine Compartment (Carb)




24. Under Right Front Seat (Carb)







25. Left Front Corner of Engine Compartment, Behind Headlight




28. Under Left Front Seat



26. Left Inner Fender Panel, Forward of Strut Tower (EFI)




27. Top Right Side of Engine, at End of Cylinder Head (EFI)



- Circuit Schematic






How The Circuit Works


With the ignition switch in "Run" or "Start," voltage is applied to the fuel pump cut-off relay. With the engine running, the fuel pump relay senses ignition pulses from the distributor. The fuel pump relay contacts close, and current flows through the relay and fuel pump to ground.

If the engine stops running while the ignition switch is in "Run" or "Start," no ignition pulses will be sent to the fuel pump cut-off relay. The relay contacts will open and the fuel pump will not operate.

1. Right Side of Engine




2. Right Rear of Engine Compartment, Above Strut Tower



3. Under Dash, Near Speedometer Connector




4. Under Carpet, Next to Driver's Door




Fuel Pump (Carb)


5. Under Carpet, on Left Rear Side of Rear Deck




8. Under Left Side of Dash, at Kick Panel




6. Rear View of Dash Fuse Box




9. Under Maintenance Access Covers, in Luggage Area




7. Under Left Side of Dash, Left of Steering Column



10. Center Rear of Hatch, Behind End Panel







Circuit Schematic



Ignition

- Circuit Schematic






How The Circuit Works


With the ignition switch in "Run" or "Start," voltage is applied to the ignition coil and the solid-state igniter in the distributor. As the distributor shaft turns, the igniter acts as a switch to control current flow through the primary winding of the ignition coil. When current flow through the primary winding is stopped, a high-voltage current is induced in the secondary winding of the ignition coil. The high-voltage current flows through the distributor cap and rotor to the proper spark plug.

The radio noise condenser helps suppress electrical radio interference.


1. Under Left Side of Dash, Left of Steering Column



2. Right Rear of Engine Compartment, Above Strut Tower




3. Right Side of Engine




Ignition


4. Front View of Dash Fuse Box




5. Rear View of Dash Fuse Box




6. Under Left Side of Dash, Left of Steering Column




7. Top Right Side of Steering Column







Starting System - Circuit Schematic



Starting System

- Circuit Schematic






How The Circuit Works


Starter Motor

With the ignition switch in "Start," and the neutral/back up lights switch closed (automatic transmission), current flows through the starter solenoid coil to ground. With manual transmission, if the clutch is depressed clutch switch B provides a path to ground, thus engaging the starter relay. The solenoid operates and current flows through the solenoid contacts and starter motor to ground: The motor engages to start the engine.


2. Bottom View of Under-hood Fuse Box




3. Under Left Side of Dash, Left of Steering Column



1. Front Corner of Engine Compartment, Below Battery




4. Front View of Dash Fuse Box




Starting System


5. Rear View of Dash Fuse Box




6. In Console, at Base of Gear Selector




7. Right Side of Engine Compartment, on Inner Fender Panel




8. Under Left Side of Dash, Left of Steering Column




9. Right Front of Engine Compartment, Forward of Battery




10. Lower Right Side of Engine







11. Behind Dash, Near Speedometer Cable




14. Under Left Side of Dash, Left of Steering Column




12. Under Side of Dash, on Heater Assembly




15. Center of Dash, Near Radio




13. Top Right Side of Steering Column



- Circuit Schematic





How The Circuit Works

Charging System

With the engine running, the alternator produces alternating current (AC) voltage. Solid-state rectifiers built into the alternator convert the AC voltage to direct current (DC) voltage for the car's electrical system. By rapidly opening and closing the ground circuit of the field, the voltage regulator controls current through the field coil, in the alternator, to keep alternator voltage output constant.

Charge Indicator


With the ignition switch in "Run" or "Start," voltage is applied to the charge indicator bulb. With the engine running and the alternator operating normally, voltage is present at the WHT/BLU wire and the charge indicator bulb. The bulb doesn't light up because voltage is present at both sides of the bulb. The WHT/RED wire is an input to indicate an electrical load on the engine. The ECU compensates for the load and adjusts idle speed. (Manual carbureted versions do not have this WHT/RED wire.)

If the ignition switch is in "Run" or "Start" and the alternator stops charging, the voltage regulator will stay grounded. In this case, there will be a negative potential felt on one side of the charge indicator bulb and the voltage regulator, thereby providing a current path to ground. The charge indicator bulb will light up to warn the driver that the alternator is not charging properly.


Choke Heater (Carb)

With the engine running and the alternator charging normally, voltage is applied through the voltage regulator to the automatic choke heater. The heater heats the bimetal coil, which unwinds and opens the choke valve. The choke valve is also controlled by the air temperature at the thermistor and by the intake air temperature sensor. The intake air temperature sensor switches the automatic choke resistor into the choke heater circuit whenever the intake air temperature is below 4.5 degrees C (40 degrees F). The automatic choke resistor reduces voltage to the automatic choke heater. This reduction in voltage slows the heating rate and delays the opening of the choke.


1. Left Front Corner of Engine Compartment, Below Battery



2. Right Front Corner of Engine Compartment, Front of Battery




3. Under Left Front Seat




Charging System and Choke Heater


4. Under Left Side of Dash, Right of Steering Column




7. Bottom View of Under-hood Fuse Box




5. Center of Engine, Right of Carburetor




8. Under Left Side of Dash, Left of Steering Column




6. Rear View of Dash Fuse Box




9. Right Side of Engine Compartment, on Inner Fender Panel






10. Under Left Front Seat




13. Left Side of Dash, Behind I/P




11. Lower Left Rear of Engine





12. Under Left Side of Dash, at Kick Panel



- Circuit Schematic







(cont'd)

Cruise Control

- Circuit Schematic (cont'd)





How The Circuit Works

The cruise control system uses mechanical, electrical, and vacuum operated devices to maintain vehicle speed at a setting selected by the driver.

System Description

The cruise control unit receives command signals from the cruise control main switch and the cruise control set/resume switch. It receives information about operating conditions from the brake switch, the distributor, the speed pulser, and the clutch switch (manual transmission), or the gear selector switch (automatic transmission). The cruise control unit also sends operational signals to the devices that regulate the throttle position. The throttle position maintains the selected vehicle speed. Essentially, the control unit compares the actual speed of the vehicle to the selected speed. Then the control unit uses the result of that comparison to open or close the throttle.

The brake switch releases the system's control of the throttle at the instant the driver depresses the brake pedal. The switch sends an electronic signal to the control unit when the brake pedal is depressed; the control unit responds by allowing the throttle to close. The clutch switch (manual transmission) or the gear selector switch (automatic transmission) sends a disengage signal input to the control unit that also allows the throttle to close.

System Operation

The cruise control system will set and automatically maintain any speed above 30 mph (45 kph). To set, make sure that the main switch is in the "On" position. After reaching the desired speed, press the set switch. The cruise control unit will receive a set signal input and, in turn, will actuate the cruise control motor.

When the set switch is depressed and the cruise control system is on, the "Cruise Control" on indicator on the warning display will light up.

You can cancel the cruise control system by pushing the main switch to "Off." This removes power to the control unit and erases the set speed from memory. If the system is disengaged temporarily by the brake switch, clutch switch, or

gear selector switch and vehicle speed is still above 30 mph, press the resume switch. With the resume switch depressed and the set memory retained, the vehicle automatically returns to the previous set speed.

For gradual acceleration without depressing the accelerator pedal, push the resume switch down and hold it there until the desired speed is reached. This will send an acceleration signal input to the control unit. When the switch is released, the system will be reprogrammed for the new speed. To slow the vehicle down, depress the set switch. This will send a deceleration signal input to the control unit, causing the vehicle to coast until the desired speed is reached. When the desired speed is reached, release the set switch. This will reprogram the system for the new speed.

Cruise Control

Troubleshooting


System Check (Road Test)

Perform the following check with the cruise control main switch "On," while driving faster than 30 mph:

1. **Depress the set switch.** The car should maintain its set speed. You shouldn't have to put your foot on the accelerator.
 2. **With your foot off the accelerator, hold the set switch in.** The car should coast to a slower speed.
 3. **Release the set switch.** The cruise control system should engage and hold the slower speed, if the speed is above 30 mph.
 4. **Hold the resume switch.** The car should accelerate.
 5. **Release the resume switch.** The car should hold the new faster speed.
 6. **Tap the brake pedal.** The cruise control system should disengage and the pilot light should go out.
 7. **Tap the resume switch.** The car should accelerate to its former speed.
- If the car has a manual transmission, repeat steps 6 and 7 by depressing the clutch. With automatic transmission, repeat steps 6 and 7 by placing the gear selector switch in "Neutral" and then to "Drive."
8. **While cruising, accelerate, then take your foot off the accelerator.** The car should coast back to the set speed.
 9. **While cruising, tap the resume switch.** The car's speed should increase about 1 mph for each tap.
 10. **While cruising, tap the set switch.** The car's speed should decrease about 1 mph for each tap.
 11. **Depress the cruise control main switch.** The cruise control should turn off.

System Diagnosis



1. Check fuses 2 and 4 of the dash fuse box and fuse 4 of the under-hood fuse box.
2. No matter what the symptoms, disconnect the control unit connector (under left side of dash) and check the wires in it for voltage and resistance.
 - **Check the voltage** at each wire listed in the first chart on page 232 (all checks are to body ground). Use a digital multimeter for all measurements.
 - If the voltage is not correct at a cavity in the connector, repair or replace the circuit that connects to that cavity, then check resistance as described below.
 - If the voltage readings are correct, make sure the ignition switch is off, then disconnect the battery.
 - **Check the resistance** of the wires listed in the second chart on page 232 (all checks are between each wire and ground).
 - If the resistance is not correct at a cavity in the connector, repair or replace the circuit that connects to that cavity.
 - If all of the resistance measurements are good, go on to step 3.
3. If you found no problems on the previous check, gently twist the connector pins on the control unit about 10 degrees with a pair of needle nose pliers to increase the contact pressure. Attach the connector to the control unit, then test drive the car again.
 - If the cruise control won't set, replace the control unit.
 - If the cruise control disconnects after some time, carefully check the control unit connector for loose terminals or other signs of poor contact.



- If the cruise control will set but won't hold its set speed, check the actuator in accordance with the Service Manual.

- If the cruise control will set but feels erratic or surges, replace the speedometer cable.

- If the speedometer cable has been replaced and the cruise control is still erratic or intermittent, measure the voltage at pin 13 with the control unit attached, the front end raised and the wheels turning at 60 mph. Voltage should be between 1.5 and 2.5 volts if the pulse generator is operating normally. If the voltage is not correct, replace the speedometer.




WIRE COLOR	CANTITY	FUNCTION	VOLTAGE	TEST CONDITIONS
RED	8	Cruise Control on indicator control	Battery	Ignition switch in "Run" and red wire grounded.
BLU	6	RPM input	Battery	Engine running.
LT GREEN	3	Throttle position signal input	Battery	Throttle switch depressed.
LT GREEN	1	Signal input	Battery	Set switch depressed.
CHRYSLER	5	Brake input	Battery	Brake pedal depressed.
GRY	12	Brake input	Battery	Ignition switch in "Run" and cruise control main switch on.
LT GRN	2	Brake input	Battery	Ignition switch in "Run" and cruise control main switch on.

Cruise Control


Resistance Check at Control Unit Connector

WIRE COLOR	CAVITY	FUNCTION	RESISTANCE	TEST CONDITIONS
BLK	11	Ground	0Ω	To body ground.
PNK (automatic transmission)	3	Disengage signal input	0Ω	Gear selector switch in D or 2.
PNK (manual transmission)	3	Disengage signal input	0Ω	Clutch pedal released.
YEL/RED	7	Speed input	23 pulses per 10 revolutions of the wheel	Measure as front drive wheel is turned by hand.
BRN	4	Common positive	80-120Ω	To body ground.
BRN/BLK	10	Vacuum valve control	80-120Ω	To body ground.
BRN/WHT	13	Vent valve control	40-60Ω	To body ground.




Voltage Check at Control Unit Connector


WIRE COLOR	CAVITY	FUNCTION	VOLTAGE	TEST CONDITIONS
LT GRN	2	Power input	Battery	Ignition switch to "Run" and cruise control main switch on.
GRY	12	Brake input	Battery	Ignition switch to "Run" and cruise control main switch on.
GRN/WHT	8	Brake input	Battery	Brake pedal depressed.
LT GRN/RED	1	Set/decel signal input	Battery	Set switch depressed.
LT GRN/BLK	9	Resume/accel signal input	Battery	Resume switch depressed.
BLU	6	RPM input	Battery	Ignition switch in "Run."
			System (13.1v)	Engine running.
RED	5	"Cruise Control" on indicator control	"Cruise Control" on indicator lights up	Ignition switch in "Run" and red wire grounded.




1. Under Left Side of Dash, on Right Side of Dash Fuse Box



2. Under Left Side of Dash, on Right Side of Steering Column




3. Under Left Side of Dash, on Brake Pedal Support Bracket




4. Under Right Side of Dash, Below Blower Assembly



5. Under Dash, Near Speedometer Connector




6. Right Rear of Engine Compartment, Above Strut Tower



Cruise Control


7. Right Side of Engine




8. Left Side of Engine Compartment, Front of Shock Tower




9. Left Front Corner of Engine Compartment, Behind Headlight




10. In Console, at Base of Gear Selector



11. Left Front Corner of Engine Compartment, Behind Bumper




12. Right Front Corner of Engine Compartment, Behind Bumper







13. Top of Steering Column




16. Rear View of Dash Fuse Box




14. Under Left Side of Dash, at Kick Panel




17. Bottom View of Under-hood Fuse Box



15. Under Left Side at Dash, Below Steering Column




18. Under Left Side of Dash, Left of Steering Column




Cruise Control



19. Right Side of Engine Compartment, on Lower Fender Panel




20. Under Left Side of Dash, at Kick Panel




21. Left Side of Dash, Behind I/P






Circuit Schematic



on Controls (Carb)



Emission Controls (Carb)

- Circuit Schematic








Emission Controls (Carb)

- Circuit Schematic (cont'd)

EMISSION CONTROL UNIT
Photo 1
Solid-state:
Do not check
resistance.





Emission Controls (Carb)

How The Circuit Works

During engine operation, the emission control unit receives signals from several input sources. The control unit uses these signal inputs to control the emission control devices explained below.

- The distributor sends ignition pulses to the emission control unit. The control unit converts these pulses to engine speed.
- The speed sensor amplifier sends vehicle speed signals to the emission control unit.
- The oxygen sensor senses the amount of oxygen in the exhaust manifold.
- The coolant temperature switch sends water temperature input to the emission control unit.

See the Charging System and Choke Heater circuit for intake air temperature sensor circuit operation.

Anti-Afterburn System

The anti-afterburn system operates during deceleration to reduce the chance of engine misfiring or backfiring. It does this by allowing air to be drawn into the intake manifold if certain conditions are met. The system is made up of two systems that operate independently: The anti-afterburn valve and its controls, and the air valve and its controls. The anti-afterburn valve operates during sudden deceleration if vehicle speed remains above 10 mph. These conditions create high manifold vacuum. The valve is operated when vacuum is applied to one side of the anti-afterburn valve diaphragm. This pulls the valve open and allows fresh air into the intake manifold. The amount of time the valve remains open depends on the strength of the manifold vacuum before the throttle was closed. The valve will close after an orifice in the valve diaphragm equalizes pressure on both sides of the diaphragm. If vehicle speed is below 10 mph, the speed sensor switch closes, opening the anti-afterburn control solenoid valve. This applies manifold vacuum to both sides of the anti-afterburn valve diaphragm and prevents it from opening.

Cranking Leak Solenoid Valve


With the engine running, vacuum is applied to the choke opener vacuum motor. This vacuum motor operates to open the choke slightly once the engine starts. With the ignition switch in "Start," voltage is applied to the cranking leak solenoid valve. When this valve operates, it prevents choke opener operation by venting vacuum from the choke opener. This operation makes it easier to start the car by providing full choke during engine cranking.

Evaporative Emission Controls

A two-way valve regulates the vapor pressure or vacuum that builds up inside the fuel tank because of changes in temperature and fuel level. Fuel vapor is allowed to escape as vapor pressure increases with temperature. The vapor is carried out through a vent line and absorbed by activated charcoal in the canister.

When the engine is not running, the air vent passages in the main and auxiliary float chambers are cut off by the valve attached to the air vent cutoff diaphragm. This allows fuel vapor in the float chambers to be vented into the charcoal canister. When the engine is running, manifold vacuum holds the air cutoff diaphragm open. The vacuum holding solenoid valve stabilizes the manifold vacuum at the diaphragm.

When the engine is not running, the fuel passages for the main and slow primary fuel metering systems are cut off by the primary slow mixture cutoff solenoid valve. This prevents fuel in the float chamber from entering the carburetor bore.



Power Valve System

This system supplies supplementary fuel to the primary main fuel passages when the car is operated in the power mode.

In normal driving modes, other than acceleration, manifold vacuum is applied to the diaphragm of the power valve and the valve stays closed. During acceleration, the throttle valve opens suddenly. This decreases the manifold vacuum and causes the power valve to open. This operation supplies additional fuel to the primary main fuel passages through the power jet, providing smooth acceleration performance.

Feedback Control System

The feedback control system maintains the proper air-fuel mixture ratio. It does this by supplying fresh air as required to the intake manifold to prevent an over-rich mixture.

The feedback control system is made up of two separate systems:

- The X-system, or main system.
- The M-system, which fine tunes the operation of the overall system.

The X-system controls the amount of air entering the intake manifold. The control unit cycles frequency solenoid valve B on and off at a rate determined by the strength of the signal from the oxygen sensor. Then manifold vacuum, which is always modulated by the constant vacuum valve, is applied to an air control valve. This allows the correct amount of air to be fed into the intake manifold.


The M-system also controls the amount of air entering the intake manifold. The control unit cycles frequency solenoid valve A, which applies EGR load sensitive vacuum to another air control valve. This feeds the correct amount of air into the intake manifold and fine tunes the system.

Secondary Air Supply System


The secondary air supply system promotes the oxidation of exhaust hydrocarbons by supplying fresh air to the exhaust manifold. It operates during deceleration and during idle when the air suction cutoff valve is open. The air suction control solenoid valve is opened by a signal from vacuum switch B. Vacuum is applied to a diaphragm in the air suction cutoff diaphragm valve. The valve operates and fresh air is drawn into the exhaust manifold by exhaust pulses.

Emission Controls (Carb)


1. Under Left Front Seat




2. Right Rear Corner of Engine Compartment




3. Left Side of Dash, Behind I/P




4. Right Side of Engine Compartment, Rear of Battery



5. Left of Engine, on Left Side of Carburetor




6. Right Front of Engine Compartment, Forward of Battery







7. Under Left Side of Dash, Right of Steering Column




10. Center of Engine, on Rear of Carburetor




8. Top Right Front of Engine




11. Left Rear Corner of Engine Compartment



9. Right Rear Corner of Engine Compartment, on Strut Tower




12. Left Front Corner of Engine Compartment




Emission Controls (Carb)


13. Left Side of Engine Compartment




16. Under Left Side of Dash, on Right Side of Dash Fuse Box




14. Right Rear of Engine, Below Air Cleaner




17. Left Side of Engine




15. In Console, at Base of Gear Selector




18. Right Rear of Engine, on Air Cleaner







19. Lower Front of Engine Compartment, Behind Right Side of Radiator




22. Bottom View of Under-hood Fuse Box




20. Right Front of Engine Compartment



23. Under Left Side of Dash at Kick Panel



21. Left Front Corner of Engine Compartment, Behind Headlight




24. On Rear of Right Inner Fender Panel




Emission Controls (Carb)


25. Right Side of Engine Compartment




28. Front of Engine




26. Below Left Side of Dash, Left of Steering Column



27. Rear View of Dash Fuse Box







Electronic Fuel Injection (EFI) Circuit Schematic



Electronic Fuel Injection (EFI)


- Circuit Schematic







Electronic Fuel Injection (EFI)

- Circuit Schematic (cont'd)








(cont'd)

Electronic Fuel Injection (EFI)

- Circuit Schematic (cont'd)







(cont'd)

- Circuit Schematic (cont'd)





Electronic Fuel Injection (EFI)

How The Circuit Works

Programmed Fuel Injection

The programmed fuel injection system provides the correct air-fuel ratio based on engine speed and absolute pressure in the manifold.

The emission control unit, which is an eight-bit microcomputer, and various sensors provide extremely accurate control of air-fuel mixture under all operating conditions. At the precise time a piston is on the intake stroke, fuel is injected into the correct intake manifold runner.

The programmed fuel injection system consists of three sub-systems: air intake, emission control, and fuel.

Air Intake System

The air intake system consists of the air cleaner, air intake, duct, throttle body, idle control system, fast idle mechanism, and intake manifold.

The idle control system controls the air-fuel ratio during idling. It consists of the emission control unit and various solenoid valves such as the idle control, fast idle, A/T idle, and A/C idle control solenoid valves. The solenoid valves change the amount of air bypassing the throttle plates into the intake manifold.

When the idle speed is reduced, due to electrical or other loads on the engine, the idle control solenoid valve opens to bypass additional air into the intake manifold. This additional air raises idle speed back to normal. The fast idle mechanism lowers the fast idle speed in steps during warm-up, but only after the coolant temperature has reached 40 degrees C.

To prevent erratic running when the engine is warming up, a higher idle speed is needed. The fast idle mechanism raises the idle when the engine is cold. The fast idle control solenoid valve opens for a specified time to bypass additional air into the intake manifold. This is dependent upon coolant temperature and atmospheric pressure.

With the automatic transmission in gear, the idle speed tends to decrease. To compensate for this, the A/T idle control solenoid valve opens to maintain the specified idle speed.

When the air conditioner is turned on, the A/C idle control solenoid opens. The A/C idle control diaphragm opens the throttle valve and raises the idle speed. The valve also opens when the coolant temperature is low (immediately after starting, and thereby ensuring stable idling regardless of the position of the A/C switch).

Emission Control System


The emission control system controls how long each injector is open. The emission control unit, the heart of the system, consists of a central processing unit, memories, and input/output ports. Basic data stored in the memories are compensated for by the signals sent from the various sensors to provide for the correct air-fuel mixture for all engine needs.

The emission control unit controls the basic discharge duration of each injector. It also controls the fuel pump and the fuel cut-off. A fail-safe system monitors the sensors and detects any malfunctions to ensure safe driving.

The CYL sensor detects the position of the no. 1 cylinder as the base for the sequential injection. The TDC sensor determines the injection timing for each cylinder and is also used to detect engine speed in establishing the basic discharge duration for different operating conditions.

The manifold air pressure sensor converts manifold air pressure readings into electrical voltage signals and sends them to the electronic control unit. This information and the signals from the crank angle sensor are used to read out the basic discharge duration from the memory.

The atmospheric pressure sensor converts atmospheric pressures into voltage signals and sends them to the emission control unit. The signals then modify the basic discharge duration to compensate for changes in atmospheric pressure.



The intake air temperature (ta) sensor uses a thermistor to measure air temperature entering the intake manifold. The basic discharge duration of the injectors is again compensated for the different operating conditions by signals sent from the sensor to the emission control unit.

The throttle angle sensor is a variable resistor. As the throttle valve is moved, the resistance varies, altering the output voltage to the control unit.

The oxygen sensor detects the oxygen content in the exhaust gas and maintains the correct air-fuel ratio. The control unit receives signals from the sensor and changes the duration during which fuel is injected.

The idle mixture adjuster sensor maintains the correct air-fuel ratio at idling when an injector is replaced. Turning the adjuster (not adjustable in the field) changes the voltage sent to the control unit, which alters the fuel discharge duration.

During engine cranking, the emission control unit detects the signal from the starter switch and increases the amount of fuel injected into the manifold, according to engine temperature. The amount of fuel injected is gradually reduced when the starter switch is released.

Fuel System


The fuel injector is a solenoid-activated constant-stroke pintle type consisting of a solenoid, plunger, needle valve and housing. When current is applied to the coil of the solenoid, the valve lifts up and pressurized fuel fills the inside of the injector. The pressurized fuel is injected close to the intake valve. Because the needle valve lift and the fuel pressure are constant, the length of time that the valve is open determines the amount of fuel injected.

The injector's timing determines its opening and closing intervals. The timing must be very accurate since it dictates the air-fuel mixture ratio. The injector must have a shortened current rise time when voltage is applied to the coil. Therefore the number of windings on the injector coil is reduced to decrease inductance. This lower resistance increases current flow through the coil, which generates a higher amount of heat. To restrict this flow of current, resistors are installed in series between the power supply and each coil.


The EFI main relay contains the main relays for the electronic control unit power supply and fuel pump power supply.

Electronic Fuel Injection (EFI)


1. Right Front Side of Engine




4. Top Left Side of Engine, Behind Valve Cover




2. Left Inner Fender Panel, Forward of Strut Tower




5. Under Carpet, Next to Driver's Door




3. Under Left Side of Dash, at Kick Panel




6. Under Carpet, on Left Side of Rear Deck







7. Under Left Front Seat




8. Front of Engine Compartment, Behind Radiator




9. Under Right Side of Dash, Below Blower Assembly




10. Top Right Center of Engine, at End of Cylinder Head



11. Top Center of Engine, Right of Fuel Injectors




12. Top Center of Engine, Rear of Air Intake Assembly




Electronic Fuel Injection (EFI)


13. Right Rear of Engine, on Air Cleaner




16. In Console, at Base of Gear Selector




14. Under Left Side of Dash, Right of Steering Column




17. Top Right Center of Engine, at End of Cylinder Head




15. Under Left Side of Dash, on Right Side of Dash Fuse Box




18. Top of Engine







19. Rear View of Dash Fuse Box




20. Bottom View of Under-hood Fuse Box




21. Under Left Side of Dash, Left of Steering Column




22. Right Side of Engine Compartment, on Inner Fender Panel



23. Under Maintenance Access Covers, in Luggage Area





24. Center Rear of Hatch, Behind End Panel





Electronic Fuel Injection (EFI)

25. Right Rear Corner of Engine Compartment




26. Under Left Side of Dash, at Kick Panel








Automatic Seat Belt Circuit Schematic



- Circuit Schematic







(cont'd)

Automatic Seat Belt

- Circuit Schematic (cont'd)





Automatic Seat Belt

How The Circuit Works


Battery voltage is applied to the automatic seat belt control unit with the ignition switch in RUN or START through fuse 2.

When you open a door, the corresponding door latch switch closes. This provides a ground for the shoulder and lap solenoids. The solenoids energize, and disable the inertia switch in the seat belt retractor. This allows you to open and close the doors freely when the seat belt is buckled without the door motion causing the seat belt retractors to lock up.


When you close a door the corresponding door latch switch opens and removes the ground for the shoulder and lap solenoids. The solenoids de-energize and enable the seat belt retractor. The seat belt retractor will lock up in the event of a sudden deceleration.

The automatic seat belt control unit monitors the shoulder and lap solenoids using switches in the driver's seat belt retractors. When the door is opened and the solenoid is energized, the switches are open. Ground is no longer applied to the automatic seat belt control unit at the switch input. When the door is closed the solenoids de-energize and the switches are closed. Ground is applied to the switch input of the automatic seat belt control unit.

The automatic seat belt system uses two indicators (door latch indicator light and driver's seat belt indicator light) in the gauge assembly, a beeper and two indicators (driver's reminder light and passenger's reminder light) in the overhead beeper/seat belt reminder light assembly to alert the driver and passenger if there is an existing problem.




1. Under Left Side of Dash, Left of Steering Column




4. Below Right Side of Dash, at Kick Panel




2. Under Left Side of Dash, at Kick Panel




5. Rear of Right Door



3. Below Left Side of Dash, Right of Steering Column




6. Under Right Door Panel, Rear of Door




Automatic Seat Belt


7. Under Right Front Seat




10. Front Center of Roof




8. Under Dash, Near Speedometer Connector




11. Upper Left Front of Trunk, Near Speaker




9. Rear View of Dash Fuse Box




12. Bottom View of Under-hood Fuse Box






13. Right Side of Engine Compartment




16. Left Side of Dash, Behind I/P



14. Rear Half of Driver's Door (Panel Removed)



17. Under Driver's Seat





15. Rear Half of Driver's Door (Panel Removed)



Trailer Adapter

- Circuit Schematic





Trailer Adapter

How The Circuit Works

The trailer adapter wiring and operation are modifications of the conventional lights.

Taillights


For information on how the circuit works, see the Taillights circuit.

Brake Lights


For information on how the circuit works, see the Brake Lights circuit.

Turn Signal and Hazard Lights


For information on how the circuit works, see the Turn Signal and Hazard Lights circuit.




1. Right Side of Engine Compartment




2. Under Left Side of Dash, at Kick Panel




3. Under Left Side of Dash, Left of Steering Column




4. Rear View of Dash Fuse Box



5. Bottom View of Under-hood Fuse Box




6. Front View of Dash Fuse Box




Trailer Adapter


7. Below Left Side of Dash, Right of Dash Fuse Box



10. Right Rear Corner of Trunk




8. Below Carpet, Next to Driver's Door Sill




11. Under Right Side of Dash, Behind Blower Assembly




9. Under Dash, Near Speedometer Connector




12. Under Carpet, on Left Rear Side of Rear Deck







13. Center Rear of Hatch, Behind End Panel



14. Under Left Side of Dash, Left of Steering Column





15. Under Left Side of Dash, Left of Steering Column



Automatic Transmission Interlock

- Circuit Schematic







How The Circuit Works

Voltage is applied at all times through fuse 4 to the brake switch. When the pedal is depressed, voltage is provided to the brake input of the interlock control unit. In "Start" or "Run" voltage is supplied through fuse 2 to the shift lock solenoid. If the brake pedal is not depressed, the interlock control unit provides ground to the shift lock solenoid, which energizes and prevents the gear shift lever from being moved from "Park" to either "Drive" or "Reverse."

1. Under Left Side of Dash, Left of Steering Column




2. Right Side of Engine Compartment




3. Under Right Side of Dash, Behind Blower Assembly



4. Under Left side of Dash, Left of Steering Column




5. Bottom View of Under-hood Fuse Box




Automatic Transmission Interlock


6. Top of Steering Column




9. Under Center Console




7. Under Left Side of Dash, Right of Steering Column




10. Under Driver's Seat




8. Under Left Side of Dash




11. Below Left Side of Dash, Right of Steering Column








12. In Console, at Base of Gear Selector



- Circuit Schematic





Radio: Honda Bose®

How The Circuit Works

With the ignition switch in "Accy" or "Run," voltage is applied through fuse 13 to the radio on-off switch and the power amplifier. When you turn the radio switch "On," current flows through this fuse into the receiver circuits and the power amplifier. The WHT/YEL wire from fuse 11 provides a memory input to the radio.


Audio Remote Switch Test

Use the chart below to troubleshoot the remote switch on the steering wheel. Measure voltage to ground at the RED wire on C226 [22-YEL] (connected) according to the chart.


Switch Depressed	Voltage of RED Wire
Nothing-Idling Condition	7.5
Volume UP ▲	3.5
Volume DOWN ▼	1.5
Selector Switch ●→●	5.4

See Section 25 of the Service Manual for switch replacement procedures if voltages are incorrect.


1. Under Left Side of Dash, Right of Steering Column




2. Under Carpet, Next to Driver's Door




3. Inside Steering Wheel




4. Rear View of Dash Fuse Box







5. Bottom View of Under-hood Fuse Box




8. Under Right Side of Rear Package Tray




6. Under Left Side of Dash, Left of Steering Column




9. Top of Steering Column



7. Right Side of Engine Compartment, on Inner Fender Panel






10. Under Center of Rear Package Tray



Radio: Honda Bose®


11. Under Left Side of Dash, Right of Steering Column



Harness Connector Views: Index For Section 202

The harness connector views in this section are shown from the **WIRE SIDE** of the **FEMALE CONNECTOR**, and only connectors with 6 or more pins are shown.

To make troubleshooting easier, the number in each cavity corresponds to the number found next to the appropriate connector on the schematic. So when troubleshooting, do so from the wire side of the female connector.



6-PIN CONNECTORS

Connector Number	Page
C107	300-2
C114	300-2
C118	300-2
C119	300-2
C120	300-2
C146	300-2
C168	300-2
C201	300-2
C205	300-2
C209	300-2
C211	300-2
C213	300-2
C230	300-3
C251	300-3
C252	300-3
C253	300-2
C315	300-2
C342	300-3
C351	300-3
C352	300-3
C362	300-2
C363	300-2
C420	300-3
C425	300-3

7-PIN CONNECTORS

C115	300-3
C128	300-3
C130	300-3
C217	300-3
C236	300-3
C309	300-3

8-PIN CONNECTORS

C104	300-3
C112	300-3

8-PIN CONNECTORS (cont'd)

Connector Number	Page
C127	300-3
C147	300-3
C243	300-3
C258	300-3
C345	300-4
C405	300-3
C406	300-3
C420	300-3

10-PIN CONNECTORS

C214	300-4
C219	300-4
C222	300-4
C317	300-4
C359	300-4

12-PIN CONNECTORS


C218	300-4
------	-------

13-PIN CONNECTORS

C224	300-4
C229	300-4
C237	300-5
C241	300-4
C302	300-5
C306	300-5

14-PIN CONNECTORS

C142	300-5
C143	300-5
C206	300-5
C216	300-5
C230	300-5



14-PIN CONNECTORS (cont'd)

Connector Number	Page
C239	300-5
C251	300-5
C266	300-5
C300	300-5

16-PIN CONNECTORS

C200	300-5
C215	300-6
C238	300-6
C244	300-6
C307	300-6
C308	300-6
C337	300-6
C390	300-6

17-PIN CONNECTORS

C336	300-6
------	-------

18-PIN CONNECTORS

C228	300-6
------	-------

20-PIN CONNECTORS

C259	300-7
C262	300-7
C263	300-7
C335	300-7

22-PIN CONNECTORS

C226	300-7
------	-------

23-PIN CONNECTORS

C225	300-7
------	-------


24-PIN CONNECTORS

C227	300-7
C304	300-7


Harness Connector Views

The harness connector views in this section are shown from the **WIRE SIDE** of the **FEMALE CONNECTOR**, and only connectors with 6 or more pins are shown.

To make troubleshooting easier, the number in each cavity corresponds to the number found next to the appropriate connector on the schematic. So when troubleshooting, do so from the wire side of the female connector




C107 C168
C118




63.030

C114
C209




63.031

C119 C146 C362
C120 C205 C363



63.036

C201 C315
C253



63.032

C211




63.037


C213



63.034




C230 C252 C351 C420
C251 C342 C352




63.033

C425




63.035

C115 C130
C128 C236




63.038

C217




63.040

C104




63.042

C112 C258
C127




63.045

C147



63.043

C243 C406
C405 C420




63.046


Harness Connector Views

The harness connector views in this section are shown from the **WIRE SIDE** of the **FEMALE CONNECTOR**, and only connectors with 6 or more pins are shown.

To make troubleshooting easier, the number in each cavity corresponds to the number found next to the appropriate connector on the schematic. So when troubleshooting, do so from the wire side of the female connector




C345




63.044

C214 C222
C219




63.048

C317 C359




63.047

C218




63.049

C224 C241




63.050


C229



63.051




C237 C306
C302




63.052

C142 C143




63.053

C206 C216



63.054

C230




63.056

C239 C300




63.055

C251




63.057

C200



63.058


C266






Harness Connector Views

The harness connector views in this section are shown from the **WIRE SIDE** of the **FEMALE CONNECTOR**, and only connectors with 6 or more pins are shown.

To make troubleshooting easier, the number in each cavity corresponds to the number found next to the appropriate connector on the schematic. So when troubleshooting, do so from the wire side of the female connector



C215 C308

															
1	2	3					4	5	6	7					
8	9	10					11	12		13	14	15	16		

63.059

C244 C390
C307

1	2	3				4	5	6	7
8	9	10	11	12	13	14	15	16	

63.062

C238

1	2	3	4	5	6	7	8
9	10	11	12	13	14	15	16


63.060

C337

21	22	23	24	25	26	27	28
29	30	31	32	33	34	35	36

63.061


C336

1	2	3	4			5	6	7	8
9	10	11	12	13	14	15	16	17	

63.063

C228

1	2	3	4	5	6	7	8	9	10
11	12		13	14	15	16		17	18



C335

1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20

63.065

C259 C262
C263

1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20

63.065

C226

1	2	3	4	5	6	7	8	9	10	11	12
13	14	15		16	17	18	19		20	21	22

63.066

C225

1	2	3	4	5	6	7	8	9	10	11	12
13	14	15	16	17	18		19	20	21	22	23

63.067

C227

1	2	3	4	5	6	7	8	9	10	11	12	13
14	15	16		17	18	19	20	21		22	23	24

63.068

C304

1	2	3	4	5	6	7	8	9	10	11	12
13	14	15	16	17	18	19	20	21	22	23	24

63.069

Request for ETM Change or Correction

The problem is with:

- ☐ Circuit schematic on page ____
(Attach a corrected copy of the schematic.)
- ☐ Component Location Index on page ____
- ☐ Photo number ____ on page ____
- ☐ How the Circuit Works on page ____
- ☐ Other (describe below)
- ☐ Troubleshooting Hints on page ____

Describe the car you worked on:

COMPLETE SERIAL NUMBER

ENGINE NUMBER

Comments:

DEALER # _____ DEALER NAME _____ SERVICE MGR'S SIGNATURE _____ DATE _____
ASV 6524-482 (8606)

Request for ETM Change or Correction

The problem is with:

- ☐ Circuit schematic on page ____
(Attach a corrected copy of the schematic.)
- ☐ Component Location Index on page ____
- ☐ Photo number ____ on page ____
- ☐ How the Circuit Works on page ____
- ☐ Other (describe below)
- ☐ Troubleshooting Hints on page ____

Describe the car you worked on:

COMPLETE SERIAL NUMBER

ENGINE NUMBER

Comments:

DEALER # _____ DEALER NAME _____ SERVICE MGR'S SIGNATURE _____ DATE _____
ASV 6524-482 (8606)

Request for ETM Change or Correction

The problem is with:

- ☐ Circuit schematic on page ____
(Attach a corrected copy of the schematic.)
- ☐ Component Location Index on page ____
- ☐ Photo number ____ on page ____
- ☐ How the Circuit Works on page ____
- ☐ Other (describe below)
- ☐ Troubleshooting Hints on page ____

Describe the car you worked on:

COMPLETE SERIAL NUMBER

ENGINE NUMBER

Comments:

DEALER # _____ DEALER NAME _____ SERVICE MGR'S SIGNATURE _____ DATE _____
ASV 6524-482 (8606)

Request for ETM Change or Correction

The problem is with:

- ☐ Circuit schematic on page ____
(Attach a corrected copy of the schematic.)
- ☐ Component Location Index on page ____
- ☐ Photo number ____ on page ____
- ☐ How the Circuit Works on page ____
- ☐ Other (describe below)
- ☐ Troubleshooting Hints on page ____

Describe the car you worked on:

COMPLETE SERIAL NUMBER

ENGINE NUMBER

Comments:

DEALER # _____ DEALER NAME _____ SERVICE MGR'S SIGNATURE _____ DATE _____
ASV 6524-482 (8606)



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

BUSINESS REPLY CARD

FIRST CLASS PERMIT NO. 426 GARDENA, CALIFORNIA

Postage will be paid by:

AMERICAN HONDA MOTOR CO., INC.
ATTN: SERVICE PUBLICATIONS
P.O. BOX 50
GARDENA, CALIFORNIA 90247-9988



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

BUSINESS REPLY CARD

FIRST CLASS PERMIT NO. 426 GARDENA, CALIFORNIA

Postage will be paid by:

AMERICAN HONDA MOTOR CO., INC.
ATTN: SERVICE PUBLICATIONS
P.O. BOX 50
GARDENA, CALIFORNIA 90247-9988



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

BUSINESS REPLY CARD

FIRST CLASS PERMIT NO. 426 GARDENA, CALIFORNIA

Postage will be paid by:

AMERICAN HONDA MOTOR CO., INC.
ATTN: SERVICE PUBLICATIONS
P.O. BOX 50
GARDENA, CALIFORNIA 90247-9988



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

BUSINESS REPLY CARD

FIRST CLASS PERMIT NO. 426 GARDENA, CALIFORNIA

Postage will be paid by:

AMERICAN HONDA MOTOR CO., INC.
ATTN: SERVICE PUBLICATIONS
P.O. BOX 50
GARDENA, CALIFORNIA 90247-9988



Contents

How To Use This Manual	1
Troubleshooting	10
Harness Routing	16
Fuse Information	22
Harness Connector Views	300
Circuit Schematics	(see Circuit Index)

Circuit Index

Air conditioner (Carb)	200
Air conditioner (EFI)	202
Automatic seat belt	264
Automatic transmission interlock	276
Back up lights	104
Blower	192
Brake lights	96
Brake warning system	128
Charging system	222
Choke heater	222
Cigarette lighter	122
Clock	122
Console lights	108
Coolant temperature gauge	146
Cruise control	226
Dash lights	108
Door courtesy lights	114
Electronic fuel injection (EFI)	248
Emission controls	238
Fans (Carb)	200
Fans (EFI)	202
Front side marker lights	90
Fuel gauge	146
Fuel pump (Carb)	210
Fuel pump (EFI)	249
Ground distribution	44
Hazard lights	84, 90
Headlights	74
Headlight retractors	78
Heater controls	196
Horn	70
Ignition	214
Ignition key light	124
Interior light	118
Key warning	124
License plate lights	100
Lights-on warning	136
Low fuel warning system	140
Oil pressure warning system	132
Parking lights	90
Power antenna	156
Power distribution	24
Power door locks	166
Power mirrors	172
Power windows	158
Radio	152
Radio-Bose®	280
Rear window defogger	184
Rear wiper/washer	180
Safety indicator	118
Seat belt warning	124
Shift position indicator	144
Starting system	218
Sunroof	188
Tachometer	150
Taillights	100
Trailer adapter	170
Trunk/hatch light	118
Turn signal lights	84
Warning indicators	140
Wiper/washer	176